



Model PX810 Performance "R"

MODEL PX810 MECHANICAL SHEAR

OPERATION, PARTS & MAINTENANCE MANUAL

| | |
|------------------|------------------------|
| Model: | Purchased From: |
| Serial #: | Date Received: |



An American Tradition Since 1910

Roper Whitney / 2833 Huffman Blvd. / Rockford, IL 61103 / 815-962-3011 / Fax 815-962-2227

www.roperwhitney.com

TABLE OF CONTENTS

| <u>SUBJECT</u> | <u>PAGE NUMBERS</u> |
|--|---------------------|
| SHEAR SPECIFICATIONS..... | 3 |
| WARRANTY INFORMATION..... | 3 |
| SAFETY LABELING AND INSTUCTIONS..... | 4-7 |
| INSTALLATION..... | 8 |
| OPERATING INSTRUCTIONS..... | 9-10 |
| BLADE CLEARANCE/ADJUSTMENT..... | 11 |
| BLADE ROTATION/REPLACING..... | 11-12 |
| BACKGAUGE INFORMATION..... | 13 |
| HOLDDOWN INFORMATION..... | 13 |
| SHEET SUPPORT SYSTEM INFORMATION..... | 14 |
| MAINTENANCE..... | 14-15 |
| PARTS VIEW AND DESCRIPTIONS..... | 16-27 |
| ELECTRICAL DIAGRAM AND PARTS LIST..... | 28 |



PX 810 Specifications

| | |
|--|------------------|
| Maximum Shearing Capacity, Mild Steel Mild Steel Rated Materials at 80,000 Tensile / 44,000 Yield | 10 gauge/3.5mm |
| Maximum Shearing Capacity, Stainless Steel Stainless Shear Rated Materials at 90,000 Tensile / 50,000 Yield | 14 gauge/2.0mm |
| Maximum Cutting Length | 97 in/2464mm |
| Back gauge Range | 30 in/762mm |
| Strokes per Minute | 45 |
| Motor-230/460v, 3-phase, 60Hz | 2 x 7.5 hp |
| Overall Dimensions, Less Gauges, LxWxH | 116 x 30 x 56 in |
| Floor Space, Gauges in Position | 116 x 72 x 56 in |
| Shipping Weight | 7500 lbs. |

3 YEAR LIMITED WARRANTY

Roper Whitney ("Manufacturer") warrants, commencing with the date of shipment to first end-user ("Customer") and for a period of thirty-six (36) months thereafter, all machinery and parts manufactured by Manufacturer to be free of defects in workmanship and material. **This warranty remains in force for the above time period only if all of Manufacturer's operational procedures are followed and recommended maintenance is performed.** If, within such warranty period, any machinery or parts manufactured by Manufacturer shall be proved to Manufacturer's satisfaction to be defective, such machinery or parts shall be repaired or replaced, at Manufacturer's option. All warranty claims are made F.O.B Manufacturer's plant, providing such machinery or parts are returned freight prepaid to Manufacturer's plant or designated service center for Manufacturer's inspection. All failed parts or components must be returned to Manufacturer prepaid for inspection before credit will be issued for new parts or components. Manufacturer's obligation hereunder shall be confined to such repair or replacement and does not include any charges, direct or indirect, for removing or replacing defective machinery or parts. No warranty shall apply to machinery, or parts or accessories, which have been furnished, repaired, or altered by others so as, in Manufacturer's judgment, to affect the same adversely or which shall have been subject to negligence, accident or improper care, installation, maintenance, storage, or other than normal use or service, during or after shipment. No warranty shall apply to the cost of repairs made or attempted outside of Manufacturer's plant or designated service center without Manufacturer's authorization. No warranty shall apply with respect to machinery or part not manufactured by Manufacturer, including but not limited to motors, accessories, electrical and hydraulic components, if such machinery or part is subject to warranty by the manufacturer of such machinery or part. No warranty claims by Customer will be honored with respect to any machinery or part from which the name and date plate has been removed or is otherwise no longer located or exhibited on such machinery or part. **THE FOREGOING WARRANTIES ARE IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY AND IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE. MANUFACTURER SHALL NOT BE SUBJECT TO ANY OTHER OBLIGATIONS OR LIABILITIES WHATSOEVER WITH RESPECT TO MACHINERY, PARTS, ACCESSORIES, OR SERVICES MANUFACTURED OR FURNISHED BY IT OR ANY UNDERTAKINGS, ACTS, OR OMISSIONS RELATING THERETO. UNDER NO CIRCUMSTANCES SHALL MANUFACTURER BE LIABLE FOR ANY CONSEQUENTIAL OR OTHER DAMAGES, EXPENSES, LOSSES, OR DELAYS HOW SO EVER CAUSED. THERE ARE NO WARRANTIES THAT EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF.**

ATTENTION

Please verify that the following safety decals are attached to the PX Shear. If you do not locate all of the decals, please contact Roper Whitney to replace any missing or unreadable safety labels.

NEVER operate this machine without the proper safety labeling.





WARNING



CRUSH AND SHEAR HAZARD

Keep clear of rear of the machine during operation.

Keep hands away from blades.



WARNING

TO PREVENT SERIOUS BODILY INJURY

NEVER PLACE ANY PART OF YOUR BODY UNDER THE RAM, HOLD-DOWN FEET, BETWEEN BLADES, BEYOND GUARDS OR AWARENESS BARRIERS UNLESS THE POWER IS OFF AND THE RAM IS BLOCKED UP.

NEVER PLACE HANDS UNDER MATERIAL BEING SHEARED OR OPERATE WITHOUT FIRST MAKING CERTAIN NO PERSON IS BEHIND THE SHEAR.

NEVER OPERATE OR MAINTAIN THIS SHEAR WITHOUT PROPER INSTRUCTION AND WITHOUT FIRST READING AND UNDERSTANDING THE OPERATORS OR SHEAR MANUAL.

IT IS THE EMPLOYER'S RESPONSIBILITY TO IMPLEMENT THE ABOVE AND MAINTAIN ALL GUARDS, BARRIERS, AND DEVICES IN PLACE AND IN PROPER WORKING ORDER.

DO NOT REMOVE THIS SIGN FROM THIS SHEAR



DANGER

Hazardous voltage.

Contact may cause electric shock or burn.

Turn off and lock-out system power before servicing.

SAFETY INSTRUCTIONS

1. Read and understand instruction manual before operating, servicing, or maintenance of machine.
2. Do not use machine beyond specified capacity.
3. Keep hands and fingers clear of cutting blade.
4. Never place any part of body between cross head and table.
5. Do not adjust back gauge while cutting material.
6. Never leave the machine running when it is unattended.
7. Provide all proper protective devices and guards that may be necessary or advisable for any particular use, operation, set-up, or service.
8. Report any equipment malfunction to your supervisor.
9. DO NOT REMOVE THIS INSTRUCTION SIGN.

SAFETY INSTRUCTIONS

1. Do not operate service or perform maintenance prior to reading and understanding the instruction manual. Become familiar with and understand the hazards and limitations of your shear.
2. Wear approved eye protection and protective footwear while operating the machine.
3. Be certain this machine is properly wired and grounded to conform to the National Electric Code. The connection of this machine to the power source should only be made by and inspected by a qualified electrician.
4. Keep hands and body parts clear of the hold down, cutter head and blade area.
5. Do not exceed the rated capacity of the machine.
6. Never leave the machine in a power on condition when unattended.
7. Always disconnect the machine from the power source before attempting maintenance, repairs or adjustments.
8. **DANGER: Do not attempt to remove the hold down before inserting and bottoming out the hold down compression bolts (71).** The compression bolts were shipped with the machine. When receiving the shear the bolts are located inside of the electrical box. Please remove them and store them in a location to be accessible.
9. Do not remove guards unless required to service the machine. Replace all protective covers prior to operation.
10. Always wear gloves to protect your hands when handling the shear blades.
11. Insure that the point of operation safeguarding is provided, used and maintained for any applicable use or service which exposes bodily hazards. For more details please refer the ANSI Standards for Shear Operations.
12. Keep the Work area around this machine clear and clean to avoid tripping or slipping.

INSTALLING THE SHEAR

The unit is shipped with a lifting bolt attached on the top of the cutter head. The shear should be lifted and positioned by using a sling or chain passed through the lifting bolt.

CAUTION: **The PX810 shear weighs approximately 7,500 lbs. net. Be sure to verify the maximum load permissible for a given chain or sling.**


Locate the machine in a well lighted area on a solid level floor. Use lag screws or bolts with expandable shields or similar holding devices through the mounting holes on each of the unit's side panels (22,51) The center line dimensions for the foundation holes can be found on the diagram supplied with the manual on page ().

The shear must be securely anchored to the floor and leveled before operating. Check the level of the shear with a machinist level both along the length and depth of the machine. Use the leveling screws (35) provided with the machine to achieve proper level. It may be advisable to slip a small section of light gauge sheet metal under the leveling screws so that their adjustment will not penetrate the floor.

ELECTRICAL SPECIFICATIONS

A wiring diagram is located in this manual and inside the electrical box (41). The connection of this machine to the power source should only be made and inspected by a qualified electrician. This machine should be properly grounded. Improper wiring may result in accidental shock which could cause grave injury or death. Motor rotation should match the directional indicators found on the motor housing. The unit is equipped with dual 230v/460v, 3 phase, 60Hz motors. The manufacture's data on the motor will detail its specifications.

PX Control Box Overlay



PX810 SHEAR CONTROL PANEL OPERATION

Please refer to the previous page which shows the 4 functions of the control panel box on your PX810 Shear

1. **On/Off Push/Pull Switch.** This switch is located on the upper left corner of the box. It is labeled 1 on the previous page. To operate the shear, turn the main disconnect power switch to the on position and pull the **Push/Pull switch** to out position until the light illuminates the switch. The shear is now ready to operate. Please note if your switch does not illuminate in the out position, you must immediately replace the bulb located within the switch. It is unsafe to operate this shear without the illuminated switch. Please contact Tennsmith if you need assistance replacing the bulb.

2. To the right of the **Push/Pull Switch** is the **Jog/Run Switch**. This selector type switch is designated 2 on the previous page. In normal shearing operation this switch should be in the **Run** position.

3. The **Jog Button** is located under the **Push/Pull switch** on the panel. It is designated 3 on the previous page. The Jog function allows the operator to engage the motor and move the cutter head of the shear up or down slowly and hold the cutter head at a particular position. A secondary function of the Jog function is move the cutter head up if material is ever wedged between the blades and stalls your machine. The primary use of the Jog function is to check the clearance between the upper and lower blades at various points within the shearing cycle.

To operate the Jog function, select **Jog** on the switch 2 in the upper right corner of the panel. Next, select either Forward or Reverse on the switch designated 4 next to the Jog switch, and finally push the Jog switch to move the cutter head of the shear.

Please note: If you are performing a check of the clearance or blade gap of the shear, the shear must be in an off position at the Push/Pull switch 1 and at the main disconnect power switch located on the outside of the box. In addition a lockout tag must be securely placed on the main electrical connection anytime you are verifying the blade clearance. If you have any questions on this procedure, please consult the factory prior to any adjustments on your shear.

4. **Stroke Selector Switch** This switch is located towards the bottom of the panel and is designated 5 on the previous page. The switch has two options:

1. Cont – This is for continuous operation of the cutter head of the shear. To engage the continuous mode, select run on switch 2 (Jog/Run Switch) and select Cont. on the stroke selector switch. With this mode the cutter head will repeat continuously a full cycle until the operator releases his foot from the foot pedal of the shear. This mode is useful when cutting short strips of material that is generally 2" or less.

2. Single – With this mode, the shear will make one complete down and up cycle each time the foot pedal is pressed. This is the standard mode of operation on this shear.

Please contact the factory if you have any questions regarding the operation of this shear.

BLADE CLEARANCE

The blade clearance on the PX810 was set at the factory to .003 in. on the ends of the blades with a .002 gap in the center of the machine. At this setting, your shear should provide satisfactory results over a broad range of materials and thickness. However, when shearing lighter gauge materials a tighter blade gap may be desired. Also, upon turning the blades to a new edge or after re-sharpening the blades, the blade clearance must be reset.

CAUTION: Checking the blade gap will require removing the wire finger guard (80). Do not operate the shear without the guard in place. To check the blade clearance, set the machine to the jog mode and jog the cutter head down so that the blades just overlap at the point at which the inspection is to take place.

WARNING: Disconnect power to the machine prior to making the measurement. Use a feeler gauge to make the measurement.

The blade clearance adjustment is made in the following manner:

1. Loosen the two table locking bolts (49) located near the mid- section of each side panel and then retighten the bolts hand tight.
2. Loosen the four table bolts (43), again reasserting only a slight amount of pressure back to each one.
3. The table positioning screws (20) located at both ends of the table are the means used to achieve the proper blade clearance. The forward screw pushes the table and bottom blade toward the cutter head. Likewise, the rear screw adjusts the blade back, thus increasing the clearance. To set the clearance, place a feeler gauge of the same thickness as the desired clearance between the two blades. Adjust the forward screw outward until the feeler gauge is locked between the blades and cannot be removed. Then adjust the rear screw in the opposite direction until the gauge stock is freed. The opposing actions of the screws serve to attain a tight, positive setting.
4. After setting the clearance on both ends of the machine, retighten the four table bolts and the two locking bolts.
5. The blade clearance in the center of the machine controlled by adjusting the center truss located at the rear of the cutter head. The blade clearance in the center of the shear should be set at least .001 closer than the dimension chosen for the ends of the blade.
6. Reposition all protective guards and covers.

Please contact the factory if you have any question regarding this procedure.

REPLACING/ROTATING BLADES

The blades on the PX Series shears are four edged blades constructed of high carbon, high chromium tool steel. Top and bottom blades are interchangeable. Upon utilizing all four edges of you blades, you may return the blades to the factory for re-sharpening or to a qualified blade re-sharpener, such as a blade manufacturer.

To remove and reposition the blades, the procedure is as follows:

1. **DANGER: Disconnect the main electrical power source to the shear.**
2. Removal of the hold down assembly (69)
 - A. **DANGER: Never attempt to remove the hold down assembly without inserting and bottoming out the hold down compression bolts (1/2" x 6" bolts shipped with the machine) which are required to contain the spring pressure of the hold down pads while the assembly is removed from the shear.** Remove the top sheet metal cover from the top of the hold down, and insert the compression bolts inside the hole mounts on top of the hold down until each bolt bottoms out.
 - B. After bottoming out the compression bolts, remove the four hex head bolts (81) which attach the hold down to the side panels on each end.
 - C. Use a sling and fork lift to remove the hold down after pulling the assembly free of the front gib screw space collars located on the side frames of the shear.
3. Removal of the top blade. **CAUTION: Use gloves to handle the blade to protect your hands.** Place a wood block wedge between the upper and lower blades. Loosen the top blade bolts starting at the ends of the blade working toward the center. Rotate the blade to a new cutting edge and reversing the procedure, reinsert and snug the bolts working from the center out to each end.
4. With all bolts in place, securely torque the bolts while insuring that the blade is properly seated in the machined blade slot of the cutter head by using either a brass or wood pry bar.
5. Repeat the above procedures similarly to reposition the bottom blade.
6. Use the procedures outlined in the **BLADE CLEARANCE** section of this manual to reset the proper baled gap. **CAUTION: Upon repositioning the shear blades, it is imperative that the bottom blade be adjusted well clear of the top blade before attempting to jog the cutter head down to make the blade clearance adjustment. Otherwise, crashing of the blades could result in severe damage to the machine.**
7. Reposition the hold down assembly.

BACKGAUGE INFORMATION

The PX shear is fitted with a front operated back gauge as standard equipment. The gauge was installed and calibrated at the factory and shipped intact mounted on the shear. Inspect the gauge carefully to determine any possible movement or damage in transit.

The gauge has 30 inches of travel. To verify the back gauge was not disturbed during shipping, rotate the hand wheel bringing the gauge into contact with the bottom blade. The display should now read zero. If the display has a value other than zero and gauge is in fact in contact with the bottom blade, the unit must be adjusted.

ADJUSTING the BACKGAUGE

When adjusting the back gauge, first determine that the two upper support shafts (123) are inserted into the welded collars at the rear of the cutter head at equal amounts. The factory setting is 1.5 inches from the face of the collar to each of the front two support brackets (128). Upon verifying this dimension, notice that each support bracket has a hex head bolt threaded into the body of the bracket. When the gauge is brought in to a zero reading on the display, the head of these bolts contact the adjusting blocks (127) and provide for a more definite stop for the readout. To perform the adjustment, bring the adjusting blocks in contact with the bolts and then adjust the threaded rods (109) connected to the stop (100) so that the stop is flush against the bottom blade at both ends of the shear. Be certain to retighten the lock nuts (115) of the threaded rod.

Hold Down Adjustment

The following is the instructions to raise the hold down height to reduce the pressure (Hold down) on your PX shear:

1. Using the jog mode, depress the jog button until the machine cutter head reaches the bottom or its lowest position.
2. Disconnect the power to the machine.
3. Remove the sheet metal cover on the top of the hold down.
4. To raise the height of the hold down pad use two 7/8" wrenches unlock the two nuts that are locked and positioned against the square tube. Turn the bottom nut against the tube for 1 complete turn. Lock the top nut against the bottom.
5. Replace the top sheet metal cover to the hold down.
6. Reconnect the power to the machine.
7. Verify the clearance or height has been raised.

SHEET SUPPORT SYSTEM


- a. **Single Stroke**: When the foot pedal is activated, the sheet support will drop down and remain down until the cycle is complete and then return to the up position.
- b. **Continuous Stroke**: When the foot pedal is activated, the sheet support will drop down and stay down as long as the foot pedal is activated. When the foot pedal is released the cutter head will return to top of the stroke and the sheet support return to the up position.
- c. **Speed of the System**: The speed of the sheet support is regulated by the two flow controls on the sheet support air valve. The pressure to the system is regulated by the Filter / Regulator unit that the air supply connects to. Generally 80 psi on the regulator will give consistent operation providing the incoming air supply is 90 psi or higher (max 150 psi). The incoming air supply should also have a flow rate of at least 5 cfm with a 3 second recovery time.
- d. **Dump Time**: Rear dump sheet support systems generally have this time set to 0 seconds. The sheet support will drop as soon as the cutter head begins its down stroke. Front dump sheet support systems have a slight delay (approximately .5 seconds) before the system drops.
Please consult the factory for adjustments for sheet support system speed.

MAINTENANCE


On a monthly basis, remove the top cover (11) of each side panel and grease the gib plates (9, 10, and 15). This can be best accomplished by jogging the cutter head down to the extreme down-stroke position, thus exposing a majority of the gib surface. **MAKE SURE THE POWER TO THE MACHINE HAS BEEN TURN OFF WHEN APPLYING LUBRICATES.** Also each month, apply grease to the zerk fitting of the support bearings (53) of the drive linkage shaft (55). Otherwise, periodic lubrication with a good grade of machine oil to the remaining moving parts such as those associated with the linkage are of the self-lubricating, oil impregnated composition. Additionally, the manufactures recommended maintenances schedule for the power unit of the shear is included in this manual as an appendix.

1. Lubrication should be performed every 30 days at points specified. Grease may extrude from bearing surface.
2. Lubrication grease specification Mobil XHP222 or equivalent.
3. SEW gear box - Oil levels and oil quality should be checked at frequent intervals, depending on usage. Oil changes are required at intervals of 10,000 operating hours or every two years, whichever comes first. If a synthetic oil lubricant is used, then this period can be extended to 20,000 operating hours or every four years, whichever comes first. In applications where hostile operating conditions exist, such as high humidity, corrosive environment, or large temperature changes, the lubricant should be changed at more frequent intervals.

Gearbox oil – Mobil Gear 630, temp +14 to +104deg F: MobilGear 629, -4 to +77 deg F or equivalent.



PX Machine PARTS View




MODEL PX810 PARTS LIST

| ITEM# | PX PART# | DESCRIPTION | QTY. |
|-------|----------|------------------------------------|------|
| 1 | 810001 | CUTTER HEAD | 1 |
| 2L | 81002L | GIBB PLATE LEFT | 1 |
| 2R | 81002R | GIBB PLATE RIGHT | 1 |
| 3 | 810003 | BLADE TOP & BOTTOM | 2 |
| 4 | 810004 | SET SCREW, ROD MOUNTING | 4 |
| 5 | 810005 | BOLT, BLADE MOUNTING | 10 |
| 6 | 810006 | LOCK WASHER, BLADE | 10 |
| 7 | 810007 | DOWEL PIN, GIBB PLATE | 8 |
| 8 | 810008 | BOLT, GIBB PLATE | 8 |
| 9 | 810009 | GIBB, CUTTER HEAD | 2 |
| 10 | 810010 | BEARING MATERIAL, GIBB | 4 |
| 11 | 810011 | TOP PLATE, SIDE PANEL | 2 |
| 12 | 810012 | NUT, REAR GIBB ADJ. | 6 |
| 13 | 810013 | SCREW, REAR GIBB ADJ. | 6 |
| 14 | 810014 | BOLT, TOP PLATE SIDE PANEL | 6 |
| 15 | 810015 | SPACER PLATE, SIDE PANEL | 2 |
| 15A | 81015A | BEARING MATERIAL SPACER | 4 |
| 16 | 810016 | BOLT, SPACER PLATE | 4 |
| 17 | 810017 | SPACER SLEEVE, HOLD DOWN | 6 |
| 18 | 810018 | SCREW, GIBB ADJ. FRONT | 6 |
| 19 | 810019 | NUT, SCREW, GIBB ADJ. FRONT | 6 |
| 20 | 810020 | BOLT, TABLE ADJ. | 4 |
| 21 | 810021 | SCREW, CONTROL BOX MOUNT | 4 |
| 22 | 810022 | SIDE PANEL, RIGHT | 1 |
| 23 | 810023 | BUSHING, COLLAR | 2 |
| 24 | 810024 | COLLAR, TREADLE MOUNT | 2 |
| 25 | 810025 | LOCK WASHER, BOLT COLLAR | 4 |
| 26 | 810026 | BOLT, COLLAR MOUNTING | 4 |
| 27 | 810027 | ARM, SWITCH TRIP | 1 |
| 28 | 810028 | BOLT, ARM MOUNTING SWITCH | 1 |
| 29 | 810029 | PIN, ARM MOUNTING SWITCH | 2 |
| 30 | 810030 | LOCK WASHER, BOLT, ARM MOUNTING | 1 |
| 31 | 810031 | NUT, ADJUSTER, SWITCH TRIP | 1 |
| 32 | 810032 | ADJUSTER, SWITCH TRIP | 1 |
| 33 | 810033 | LIMIT SWITCH | 1 |
| 34 | 810034 | SCREW, SWITCH MOUNTING | 2 |
| 35 | 810035 | BOLT, LEVEL ADJUSTING | 4 |
| 36 | 810036 | NUT, BOLT, LEVEL ADJUSTING | 4 |
| 37 | 810037 | BOLT, SUPPORT BEAM MOUNTING | 4 |
| 38 | 810038 | SCREW, COVER MOUNTING SWITCH | 4 |
| 39 | 810039 | COVER, SWITCH | 1 |
| 40 | 810040 | SCREW, SPACER PLATE MOUNTING, SIDE | 4 |

MODEL PX810 PARTS LIST Continued

| ITEM# | PX PART# | DESCRIPTION | QTY. |
|--------------|-----------------|--|-------------|
| 41 | 810041 | ELECTRIC CONTROL BOX | 1 |
| 42 | 810042 | SWITCH, FORWARD REVERSE | 1 |
| 43 | 810043 | BOLT, TABLE MOUNTING, TOP | 4 |
| 44 | 810044 | BOLT, MATERIAL GUIDE BAR MOUNTING | 4 |
| 45 | 810045 | MATERIAL GUIDE BAR | 2 |
| 46 | 810046 | SCREW, SCALE MOUNTING, TABLE | 2 |
| 47 | 810047 | SCALE, TOP | 2 |
| 48 | 810048 | TABLE | 1 |
| 49 | 810049 | BOLT, TABLE MOUNTING, ENDS | 2 |
| 50 | 810050 | FLAT WASHER, BOLT, TABLE MOUNTING | 2 |
| 51 | 810051 | SIDE PANEL, LEFT | 1 |
| 52 | 810052 | BOLT, BEARING BLOCK MOUNTING | 2 |
| 52A | 81052A | BOLT, BEARING BLOCK MOUNTING | 2 |
| 53 | 810053 | BEARING BLOCK, UPPER | 2 |
| 54 | 810054 | BEARING BLOCK, LOWER | 2 |
| 55 | 810055 | DRIVE SHAFT | 1 |
| 55R | 810055R | SPACER, SNAP RING, DRIVE SHAFT LINK | 6 |
| 56L | 810056L | ELECTRIC GEAR MOTOR | 1 |
| 56R | 810056R | ELECTRIC GEAR MOTOR | 1 |
| 57L | 810057L | BOLT, MOTOR AND GEAR BOX MOUNTING | 4 |
| 58R | 810058R | KEY, SHAFT, GEAR BOX | 1 |
| 57L | 810057L | BOLT, MOTOR AND GEAR BOX MOUNTING | 4 |
| 59R | 810059R | BOLT, ARM AND PIN ASSEMBLY, GEAR BOX SHAFT | 1 |
| 59L | 810059L | BOLT, ARM AND PIN ASSEMBLY, GEAR BOX SHAFT | 1 |
| 60R | 810060R | ARM AND PIN ASSEMBLY, GEAR BOX FRONT LINK | 1 |
| 60L | 810060L | ARM AND PIN ASSEMBLY, GEAR BOX FRONT LINK | 1 |
| 61 | 810061 | BEARING MATERIAL, BEARING BLOCK | 2 |
| 62 | 810062 | SUPPORT BEAM | 1 |
| 63R | 810063R | LINK, FRONT | 1 |
| 63L | 810063L | LINK, FRONT | 1 |
| 64 | 810064 | LINK, REAR | 2 |
| 65 | 810065 | REAR CHUTE | 1 |
| 66 | 810066 | SCREW, REAR CHUTE MOUNTING | 5 |
| 67 | 810067 | RETAINER RING, LINK MOUNTING | 6 |
| 68 | 810068 | SPACER, LINK | 12 |
| 69 | 810069 | HOLD DOWN | 1 |
| 70 | 810070 | BOLT, HOLD DOWN MOUNTING | 4 |
| 71 | 810071 | JACK SCREW, HOLD DOWN | 6 |
| 72 | 810072 | NUT, STUD, FOOT MOUNTING, HOLD DOWN | 10 |
| 73 | 810073 | STUD, FOOT MOUNTING, HOLD DOWN | 10 |
| 74 | 810074 | BUSHING, QUILL, HOLD DOWN | 10 |
| 75 | 810075 | FOOT, HOLD DOWN | 10 |
| 76 | 810076 | RUBBER PAD, FOOT, HOLD DOWN | 10 |
| 77 | 810077 | FINGER GUARD, HOOLD DOWN | 1 |
| 78 | 810078 | SCREW, FINGER GUARD MOUNTING | 6 |
| 79 | 810079 | FOOT SWITCH | 1 |
| 79A | 81079A | CABLE, FOOT SWITCH | 1 |


PX 2x Back gauge Crank Assembly



PX 2x Back gauge Crank Assembly Parts List

| ITEM# | PX PART# | DESCRIPTION | QTY. |
|-------|----------|---|------|
| 83 | 20083 | THRUST WASHER | 5 |
| 85 | 20085 | LOCK WASHER, BOLT, SPROCKET MOUNTING | 8 |
| 86 | 20086 | SPACER RING, SPROCKET MOUNTING | 4 |
| 87 | 20087 | BEARING, SPROCKET MOUNTING | 4 |
| 88 | 20088 | SPROCKET | 8 |
| 89 | 20089 | CHAIN | 1 |
| 102 | 20102 | BOLT, SPROCKET AND SPACER BLOCK MOUNTING | 3 |
| 103 | 20103 | FLAT WASHER, BOLT, SPROCKET SPACER BLOCK | 3 |
| 139 | 20139 | SCREW, CRANK COVER MOUNTING | 4 |
| 140 | 20140 | LOCK WASHER, CRANK COVER MOUNTING | 4 |
| 146 | 20146 | STRIPPER BOLT, IDLER SPROCKET MOUNTING | 3 |
| 147 | 20147 | BEARING, IDLER SPROCKET | 3 |
| 148 | 20148 | IDLER SPROCKET | 3 |
| 150 | 20150 | NUT, STRIPPER BOLT, IDLER SPROCKET | 3 |
| 151 | 20151 | BOLT, IDLER SPROCKET BRACKET MOUNTING | 12 |
| 152 | 20151 | LOCK WASHER, BOLT, IDLER SPROCKET BRACKET | 12 |
| 153 | 20153 | BRACKET, IDLER SPROCKET MOUNTING | 1 |
| 174 | 20174 | BOLT, HANDLE MOUNTING | 1 |
| 175 | 20175 | HANDLE, CRANK | 1 |
| 176 | 20176 | CRANK | 1 |
| 177 | 20177 | NUT, BOLT, HANDLE MOUNTING | 1 |
| 178 | 20178 | SCREW, CRANK MOUNTING | 4 |
| 179 | 20179 | COVER, CRANK | 1 |
| 180 | 20180 | ACEME NUT, LOCK HANDLE | 2 |
| 181 | 20181 | NUT, LOCK HANDLE | 1 |
| 182 | 20182 | LOCK, CRANK BLOCK | 1 |
| 183 | 20183 | STUD, LOCK HANDLE | 1 |
| 184 | 20184 | SPACER, LOCK HANDLE | 1 |
| 185 | 20185 | NUT, LOCK HANDLE MOUNTING | 1 |
| 186 | 20186 | HANDLE, LOCK MOUNTING | 1 |
| 187 | 20187 | SPRING, LOCK HANDLE MOUNTING | 1 |
| 188 | 20188 | SCREW, HANDLE MOUNTING | 1 |
| 189 | 20189 | SPACER, SPROCKET MOUNTING | 1 |
| 190 | 20190 | SCREW, SPROCKET MOUNTING | 4 |
| 191 | 20191 | SPACER, SET SCREW | 1 |
| 192 | 20192 | SET SCREW | 1 |
| 193 | 20193 | STUD, LOCK MOUNTING | 1 |
| 194 | 20194 | SPACER, STUD | 1 |
| 195 | 20195 | BRACKET, IDLER SPROCKET BRACKET MOUNTING | 1 |

PX 2x Back gauge Pointer Assembly



PX 2x Back gauge Pointer Assembly Parts List

| ITEM# | PX PART# | DESCRIPTION | QTY. |
|-------|----------|---|------|
| 136 | 20136 | COVER, SCALE POINTER ASSEMBLY | 1 |
| 137A | 2137A | SCALE, INCH/METRIC 30 ICHES | 1 |
| 138 | 20138 | SCREW, SCALE BRACKET AND COVER MOUNTING | 3 |
| 139 | 20139 | LOCK WASHER, SCREW, SCALE BRACKET | 3 |
| 140 | 20140 | BRACKET, SCALE MOUNTING | 1 |
| 141 | 20141 | BRACKET, ROD MOUNTING | 2 |
| 142 | 20142 | SET SCREW, ROD MOUNTING | 2 |
| 143 | 20143 | BOLT, BRACKET MOUNTING | 2 |
| 144 | 20144 | LOCK WASHER, BOLT, BRACKET MOUNTING | 2 |
| 145 | 20145 | CHAIN | 1 |
| 146 | 20146 | STRIPPER BOLT, IDLER SPROCKET MOUNTING | 3 |
| 147 | 20147 | BEARING, IDLER SPROCKET | 3 |
| 148 | 20148 | IDLER SPROCKET | 3 |
| 150 | 20150 | NUT, STRIPPER BOLT, IDLER SPROCKET | 3 |
| 151 | 20151 | BOLT, IDLER SPROCKET BRACKET MOUNTING | 12 |
| 152 | 20151 | LOCK WASHER, BOLT, IDLER SPROCKET BRACKET | 12 |
| 153 | 20153 | BRACKET, IDLER SPROCKET MOUNTING | 1 |
| 154 | 20154 | BRACKET, IDLER SPROCKET BRACKET | 1 |
| 155 | 20155 | BLOCK, POINTER MOUNTING | 1 |
| 156 | 20156 | RETAINER, BEARING MOUNTING | 2 |
| 157 | 20157 | TEFLON PIN, POINTER BLOCK | 2 |
| 158 | 20158 | SPRING, POINTER BLOCK | 2 |
| 159 | 20159 | SET SCREW, POINTER BLOCK | 2 |


PX 2x Back gauge Pointer Assembly Parts List

| ITEM# | PX PART# | DESCRIPTION | QTY. |
|--------------|-----------------|-------------------------------------|-------------|
| 160 | 20160 | NUT, SET SCREW, POINTER BLOCK | 2 |
| 161 | 20161 | CLAMP, CHAIN LOCK, POINTER BLOCK | 1 |
| 162 | 20162 | BOLT, CLAMP MOUNTING, POINTER BLOCK | 2 |
| 163 | 20163 | BEARING, POINTER BLOCK | 1 |
| 164 | 20164 | SCREW, POINTER MOUNTING | 2 |
| 165 | 20165 | POINTER, SCALE | 1 |


PX 2x Back gauge Drive Assembly Parts List

| ITEM# | PX PART# | DESCRIPTION | QTY. |
|--------------|-----------------|---|-------------|
| 81 | 20081 | BOLT, BRACE MOUNTING | 2 |
| 82 | 20082 | LOCK WASHER, BOLT, BRACE MOUNTING | 2 |
| 83 | 20083 | THRUST WASHER | 5 |
| 84 | 20084 | BOLT, SPROCKER MOUNTING | 8 |
| 85 | 20085 | LOCK WASHER, BOLT, SPROCKET MOUNTING | 8 |
| 129 | 20129 | LOCK WASHER, BOLT, SPROCKET MOUNTING | 8 |
| 86 | 20086 | SPACER RING, SPROCKET MOUNTING | 4 |
| 87 | 20087 | BEARING, SPROCKET MOUNTING | 4 |
| 88 | 20088 | SPROCKET | 8 |
| 89 | 20089 | CHAIN | 1 |
| 90 | 20090 | SPACER BLOCK, SPROCKET AND CRANK MOUNTING | 1 |
| 91 | 20091 | CHAIN | 1 |
| 92 | 20092 | SPACER RING, SPROCKET MOUNTING | 3 |
| 93 | 20093 | SHAFT, SPACER BLOCK AND SPROCKET MOUNTING | 1 |
| 95 | 20095 | SUPPORT BLOCK, FRONT | 2 |
| 125 | 20125 | SHAFT, SPROCKET ASSEMBLY MOUNTING LEFT | 1 |

PX 2x Back gauge Drive Assembly




PX 2x Back gauge Arm Assembly



PX 2x Back gauge Arm Assembly Parts List

| ITEM# | PX PART# | DESCRIPTION | QTY. |
|-------|----------|---|------|
| 94 | 20094 | SET SCREW, SHAFT MOUNTING | 4 |
| 95 | 20095 | SUPPORT BLOCK, FRONT | 2 |
| 96 | 20096 | SET SCREW, SUPPORT BLOCK MOUNTING | 8 |
| 97 | 20097 | SUPPORT ROD | 2 |
| 98 | 20098 | SUPPORT BLOCK, REAR | 2 |
| 99 | 20099 | BOLT, REAR SUPPORT BLOCK ADJUSTING | 2 |
| 100 | 20100 | JAM NUT, BOLT, REAR SUPPORT BLOCK ADJ | 2 |
| 101 | 20101 | SHAFT, SPROCKET MOUNTING, REAR | 2 |
| 102 | 20102 | BOLT, SPROCKET AND SPACER BLOCK MOUNTING | 3 |
| 103 | 20103 | FLAT WASHER, BOLT, SPROCKET SPACER BLOCK | 3 |
| 104 | 20104 | CHAIN, ROLLER ASSEMBLY | 2 |
| 109 | 20109 | SPACER BLOCK AND ROD HOLDER, ROLLER ASSY. | 4 |
| 110 | 20110 | BOLT, SWIVEL AND ROLLER ASSEMBLY | 20 |
| 111 | 20111 | LOCK WASHER, SWIVEL AND ROLLER ASSEMBLY | 2 |
| 114 | 20114 | SPACER, SWIVEL AND ROLLER ASSEMBLY | 40 |
| 115 | 20115 | SET SCREW, BRACKET MONTING ROLLER ASSY. | 8 |
| 116 | 20116 | JAM NUT, BRACKET MOUNTING, ROLLER ASSY. | 8 |
| 117 | 20117 | BRACKET, ROLLER ASSEMBLY | 2 |
| 118 | 20118 | CLAMP, CHAIN LOCK, ROLLER ASSEMBLY | 2 |
| 119 | 20119 | BOLT, CLAMP MOUNTING, CHAIN LOCK | 4 |
| 120 | 20120 | SPOOL, ROLLER ASSEMBLY | 8 |
| 121 | 20121 | SHAFT, SPOOL MOUNTING ROLLER ASSEMBLY | 8 |
| 122 | 20122 | BEARING, SPOOL, ROLLER ASSEMBLY | 16 |
| 123 | 20123 | TEFLON WASHER, ROLLER ASSEMBLY | 16 |
| 124 | 20122 | SIDE PLATE, ROLLER ASSEMBLY | 2 |
| 129 | 20129 | BOLT, COVER MOUNTING | 8 |
| 130 | 20130 | FLAT WASHER, BOLT, COVER MOUNTING | 8 |
| 131 | 20131 | COVER, LEFT | 1 |
| 132 | 20132 | COVER, RIGHT | 1 |
| 138 | 20138 | SCREW, COVER MOUNTING | 18 |
| 167 | 20167 | STOP, BACKGAUGE | 1 |
| 168 | 20168 | BRACKET, STOP MOUNTING LEFT | 1 |
| 168A | 2168A | BRACKET, STOP MOUNTING RIGHT | 1 |
| 169 | 20169 | BOLT, STOP BRACKET MOUNTING | 4 |
| 170 | 20170 | LOCK WASHER | 4 |
| 171 | 20171 | FLAT WASHER | 4 |
| 172 | 20172 | JAM NUT, STOP BRACKET MOUNTING ROD | 10 |
| 173 | 20173 | ROD, ALL THREAD | 2 |


PX Four Foot Squaring Arm



PX Four Foot Squaring Arm Parts List

| ITEM# | PX PART# | DESCRIPTION | QTY. |
|-------|----------|--|------|
| 5 | 40005 | BOLT, TABLE, SQUARING ARM MOUNTING | 2 |
| 6 | 40006 | LOCK WASHER, BOLT, TABLE SQ ARM MOUNTING | 2 |
| 46 | 40046 | SET SCREW, SCALE | 5 |
| 181 | 40181 | NUT, LOCK HANDLE, BLOCK SQ ARM | 1 |
| 185 | 40185 | RATCHET STUD, LOCK HANDLE, BLOCK SQ ARM | 1 |
| 186 | 40186 | HANDLE, LOCK HANDLE, BLOCK SQ ARM | 1 |
| 187 | 40187 | SPRING, LOCK HANDLE, BLOCK SQ ARM | 1 |
| 188 | 40188 | SCREW, LOCK HANDLE, BLOCK SQ ARM | 1 |
| 211 | 40211 | THREADED STUD, LOCK HANDLE, BLOCK SQ ARM | 1 |
| 212 | 40212 | TEFLON STUD, LOCK HANDLE, BLOCK SQ ARM | 1 |
| 213 | 40213 | STOP BLOCK, SQUARING ARM | 1 |
| 214 | 40214 | SET SCREW, STOP BLOCK | 1 |
| 215 | 40215 | PIVOT BLOCK, STOP BLOCK | 1 |
| 216 | 40216 | STUD, PIVOT BLOCK, STOP BLOCK | 1 |
| 217 | 40217 | SCREW, GUIDE BAR, SQUARING ARM | 5 |
| 218 | 40218 | GUIDE BAR, FOUR FOOT, SQUARING ARM | 1 |
| 219 | 40219 | MATERIAL, GUIDE, FOUR FOOT, SQUARING ARM | 1 |
| 220 | 40220 | SCALE, FOUR FOOT, SQUARING ARM | 1 |
| 221 | 40221 | ARM, FOUR FOOT, SQUARING ARM | 1 |
| 222 | 40222 | LEG, FOUR FOOT, SQUARING ARM | 1 |
| 223 | 40223 | WASHER, BASE, LEG MOUNTING | 2 |
| 224 | 40224 | BOLT, BASE, LEG MOUNTING | 2 |
| 225 | 40225 | FLOOR MOUNT, SQUARING ARM | 1 |
| 226 | 40226 | NUT, FLOOR MOUNT, SQUARING ARM | 2 |


PX Front Return Sheet Support System



PX Front Return Sheet Support System

| ITEM# | PX PART# | DESCRIPTION | QTY. |
|-------|----------|--|------|
| 195 | FS10195 | SUPPORT BRACKET, FRONT RETURN, SYSTEM | 1 |
| 195A | FS10195A | SUPPORT BRACKET, FRONT RETURN, SYSTEM | 1 |
| 197 | FS10197 | LOCK WASHER, BRACKET MOUNTING | 6 |
| 198 | FS10198 | SCREW, BRACKET MOUNTING | 6 |
| 199 | FS10199 | WASHER, RACK MOUNTING | 2 |
| 200 | FS10200 | TEFLON WASHER, RACK MOUNTING | 2 |
| 201 | FS10201 | STRIPPER BOLT, RACK MOUNTING | 2 |
| 202 | FS10202 | BRACKET, AIR CYLINDER MOUNTING | 2 |
| 203 | FS10203 | LOCK WASHER, AIR CYLINDER MOUNTING | 4 |
| 204 | FS10204 | SCREW, AIR CYLINDER MOUNTING | 4 |
| 205 | FS10205 | AIR CYLINDER, SHEET SUPPORT SYSTEM | 2 |
| 206 | FS10206 | CLEVIS, AIR CYLINDER | 2 |
| 207 | FS10207 | PIN, CLEVIS, AIR CYLINDER | 2 |
| 208 | FS10208 | RACK, SHEET SUPPORT SYSTEM, FRONT RETURN | 1 |
| 209 | FS10209 | COVER, LINK, SHEET SUPPORT SYSTEM | 2 |
| 210 | FS10210 | SCREW, COVER, LINK | 4 |

PX Rear Sheet Support System




PX Rear Sheet Support System Parts List

| ITEM# | PX PART# | DESCRIPTION | QTY. |
|-------|----------|--|------|
| 197 | RS5197 | SCREW, BRACKET MOUNTING | 4 |
| 198 | RS5198 | LOCK WASHER, BRACKET MOUNTING | 4 |
| 199 | RS5199 | WASHER, RACK MOUNTING | 2 |
| 200 | RS5200 | TEFLON WASHER, RACK MOUNTING | 2 |
| 201 | RS5201 | STRIPPER BOLT, RACK MOUNTING | 2 |
| 202 | RS5202 | BRACKET, AIR CYLINDER MOUNTING | 2 |
| 203 | RS5203 | LOCK WASHER, AIR CYLINDER MOUNTING | 4 |
| 204 | RS5204 | SCREW, AIR CYLINDER MOUNTING | 4 |
| 205 | RS5205 | AIR CYLINDER, SHEET SUPPORT SYSTEM | 2 |
| 206 | RS5206 | CLEVIS, AIR CYLINDER | 2 |
| 207 | RS5207 | PIN, CLEVIS, AIR CYLINDER | 2 |
| 208 | RS5208 | RACK, SHEET SUPPORT SYSTEM, FRONT RETURN | 1 |
| 209 | RS5209 | RACK, REAR, SHEET SUPPORT SYSTEM | 1 |
| 210 | RS5210 | BRACKET, REAR SHEET SUPPORT, MOUNTING | 2 |
| 211 | RS5211 | STRIPPER BOLT, REAR, RACK MOUNTING | 2 |

PX8-10 Dual Cutter Head Motor

High Voltage Mains, AC Circuit



Roper Whitney
2833 Huffman Blvd
Rockford, IL
PAC 03-04-2013

Motors and Brakemotors

Type BM (G) Brakes

OPERATING INSTRUCTIONS

09 793 67 US

General

Every SEW-Eurodrive motor is thoroughly tested, checked, and properly packed prior to shipment. However, please check immediately upon arrival for shortage of parts or transit damage. Note the damage or shortage on the freight bill of lading and file a claim with the carrier. Also, notify SEW-Eurodrive of the shortage or damage.

Installation

For motors mounted integrally to a gear unit, please refer to the Operating Instructions for Gearmotors and Gear Reducers for proper installation of the drive. The drive installation site should be selected to ensure:

- Ambient temperatures below 40°C (104°F).
- Unimpeded flow of air to the motor and variable speed units.
- Accessibility to gear unit, oil plugs.
- Adequate space for the removal of the brakemotor fanguard for brake adjustment and maintenance.

The drive unit should be mounted on a flat, vibration damping, and torsionally rigid structure. The flatness tolerance of the supporting surface should not exceed:

For motor size 180 and smaller — 0.004 inch
For motor size above 180 — 0.008 inch

Do not hammer on the shafts to install couplings, sheaves, etc. Hammering can cause brinelling of the bearings and a reduction in bearing life. We recommend heating the components to approximately 175°F and sliding them on. This will reduce possible damage to the bearings. In addition, there is a metric tapped hole in the center of the motor shaft that can be utilized with a tool to press on or remove the coupling, sheaves, etc.

The motor shaft diameters are metric and have tolerances as listed in the SEW-Eurodrive catalogs. Shaft couplings should be properly aligned to prevent vibration, coupling wear and premature failure of the shaft bearings.

Maximum Parallel Offset — 0.003 inch
Maximum Angular Offset — 0.030°

To prevent the output shaft and bearings from being subjected to excessive loads, the maximum overhung loads, as shown in SEW-Eurodrive catalogs, should not be exceeded. Please consult our engineering department if the load may exceed the recommended figure given or where there are combined radial and axial loads. In such cases, the exact operating conditions must be stated including speed, direction of rotation, position, magnitude and direction of the external radial and axial loads being applied.

Long Term Storage

If the motor must be stored for a long period of time without operating, the motor must be stored in a dry, protected area, and in the mounting position indicated on the unit nameplate. In order to ensure that the motor has not been damaged by moisture after a prolonged storage, the insulation resistance should be checked. An insulation tester with a measurement voltage of at least 500V (e.g. magneto generator) should be used for this purpose. The insulation resistance is sufficient if it has an ohmic

value of at least $1000 \times V_N$ (e.g. at $V_N = 230\text{VAC}$: $R_{\text{insul}} \geq 230000$ ohms = 0.23M ohms). If the measured value is smaller, the motor should be dried before use (for example, with hot air up to a maximum of 90°C or by resistance heating with an auxiliary AC voltage of 10% of V_N via an isolating transformer). Care should be taken to ensure that the motor is heated with not more than 20% of its rated current and that the rise in temperature is not more than 90°C. The drying procedure can be stopped when the insulation resistance has reached $500000 = 0.5\text{M}$ ohms.

Severe Duty Units

Severe Duty Units are indicated with the letters “-KS” at the end of the motor type on the motor nameplate. Severe Duty units include drain holes in the motor end bells and conduit box at the lowest points allowing condensation to drain out of the motor.

CAUTION!

The drain holes are installed for the mounting position listed on the gearbox nameplate. Installing a unit in a mounting position other than what is shown on the nameplate will reposition the condensation drain holes. As a result, the drain holes may not be located at the lowest point and may not allow water to drain. This can cause premature drive failure.

Electrical Connection

The motor must be installed and connected by a qualified electrician who is knowledgeable with the NEC article 430 and local regulations. He must make sure that the voltage and frequency of the electrical supply correspond with the data stamped on the motor nameplate before connecting the motor in accordance with the wiring diagram, which can be found in the terminal box. For brake connections, see the following pages.

At installation the electrician must make sure that the terminal block jumpers are positioned correctly and that all electrical connections including the ground connection are secure. In order to effectively protect the motor from overloads, appropriate motor protection must be provided. Fuses do not always provide adequate motor protection. For motors which are required to operate with a very high start-stop frequency, the overload heater type motor protection is insufficient. It is advisable in such applications to provide the motor with temperature sensors (thermistors) in the windings. Monitor the thermistors by means of an external trip device. In this way, the motor will be fully protected against practically all possible overloads.

When using motors outdoors or in washdown applications the cable entries into the terminal box must be directed downward to prevent water from entering the conduit box. The unused cable entries must be closed off properly.

Lubrication and Maintenance

WARNING! Always ensure equipment is secure and electrical power is off before removing or performing maintenance on the drive assembly. The motor bearings are sealed and the grease content is adequate for the life of the bearing.

SEW
EURODRIVE

**SOUTHEAST MANUFACTURING
& ASSEMBLY CENTER**
1295 Spartanburg Highway/Lyman SC 29365
(864) 439-7537 Fax: (864) 439-7830

SOUTHWEST ASSEMBLY CENTER
3950 Platinum Way/Dallas TX 75237
(214) 330-4824 Fax: (214) 330-4724

MIDWEST ASSEMBLY CENTER
2001 West Main Street/Troy OH 45373
(937) 335-0036 Fax: (937) 222-4104

EAST COAST ASSEMBLY CENTER
200 High Hill Road/Bridgeport NJ 08014
(856) 467-2277 Fax: (856) 845-3179

WEST COAST ASSEMBLY CENTER
30599 San Antonio Road/Hayward CA 94544
(510) 487-3560 Fax: (510) 487-6381



Brake Coil Resistance

| Motor Frame | | DT71-80 | DT80 | DT90-100 | DT100 | DV112-132S | DV132M-160M | DV160L-225 |
|--------------------------|-----|---------------|---------------|---------------|---------------|---------------|---------------|---------------|
| Brake Size | | BM(G)05 | BM(G)1 | BM(G)2 | BM(G)4 | BM(G)8 | BM15 | BM30/31/32/62 |
| Brake Torque (lb-ft) | | 0.89 - 3.7 | 4.4 - 7.4 | 3.7 - 14.8 | 17.7 - 29.5 | 7.00 - 55.3 | 18.4 - 110.6 | 36.9 - 442.5 |
| BRAKE VOLTAGE | | $R_B(\Omega)$ | $R_B(\Omega)$ | $R_B(\Omega)$ | $R_B(\Omega)$ | $R_B(\Omega)$ | $R_B(\Omega)$ | $R_B(\Omega)$ |
| AC (to rectifier V_B) | DC | $R_T(\Omega)$ | $R_T(\Omega)$ | $R_T(\Omega)$ | $R_T(\Omega)$ | $R_T(\Omega)$ | $R_T(\Omega)$ | $R_T(\Omega)$ |
| — | 24 | 4.3 13.2 | 3.8 11.8 | 3.3 10.3 | 7 8.2 | 1.6 8.2 | 0.8 5.0 | 0.7 5.3 |
| 105-116 | 48 | 17.1 52.5 | 15.2 47.0 | 13.3 40.9 | 10.7 32.7 | 6.2 32.7 | 3.1 20.1 | 2.8 21.1 |
| 186-207 | 80 | 54.0 166 | 48.1 149 | 42.1 129 | 33.8 103 | 19.6 103 | 9.8 63.5 | 8.9 66.7 |
| 208-233 | 96 | 68.0 209 | 60.5 187 | 53.0 163 | 42.5 130 | 24.7 130 | 12.4 80.8 | 11.2 84.0 |
| 330-369 | 147 | 171 525 | 152 470 | 133 409 | 107 327 | 62 327 | 31.1 201 | 28.1 211 |
| 370-414 | 167 | 215 661 | 191 591 | 168 515 | 134 411 | 78.1 411 | 39.2 253 | 35.4 266 |
| 415-464 | 185 | 271 832 | 241 744 | 211 649 | 169 518 | 98.3 518 | 49.3 318 | 44.6 334 |
| 465-522 | 208 | 341 1047 | 303 937 | 266 817 | 213 652 | 110 577 | 62.1 401 | 56.1 421 |

Voltage AC - The voltage shown is the nameplate AC brake voltage supplied to the brake rectifier.

DC - The voltage shown is the effective DC voltage required by the brake coil. The measured voltage from the rectifier will be 10-20% lower than that shown.

Brake Coil Resistance - values must be measured with the brake coil disconnected from the rectifier.

R_B - Accelerator coil resistance in Ω , measured from the red to the white brake coil wire.

R_T - Fractional coil resistance in Ω , measured from the white to the blue brake coil wire.


Brake Connection (AC Voltage)

SEW-Eurodrive motor brakes can be connected in a number of different ways. In order to connect the brake for each application, it is important to refer to the data on the motor nameplate that describes the brake system. The brake fields are: brake voltage, brake torque and brake control.

This operating instruction covers AC brake voltages with the following brake control components. If the brake voltage is DC, or if the brake control components differ from those listed below, an additional operating instruction must be consulted for connection information.

SEW-Eurodrive fail-safe mechanical brakes are DC controlled. Standardly, a brake rectifier (halfwave) is provided to convert the AC line voltage to the DC voltage required to drive the brake. 24VDC brakes do not include a rectifier. When voltage (V_B) is applied to the brake, it will release. When voltage (V_B) is removed from the brake, it will set. The brake rectifier can be wired either for normal brake reaction time (setting, stopping) or fast brake reaction time. The fast brake reaction will set the brake more quickly which will provide a shorter and more repeatable stopping distance. There are two basic types of brake rectifiers, BG and

| Brake Control (Rectifier) | Part Number |
|---------------------------|-------------|
| BG1.5 | 825 384 6 |
| BG3.0 | 825 386 2 |
| BGE1.5 | 825 385 4 |
| BGE3.0 | 825 387 0 |



BGE. The BG brake rectifier is standard on motor sizes DT71 - DT100. The BGE rectifier is standard on motor sizes DV112 - DV225. The BGE rectifier can be ordered with motor sizes DT71 - DT100 and will provide faster brake release times allowing the motor to cycle more frequently.

The wiring diagrams for brake connections are located on the inside of the motor conduit box lid. The brake will release and allow the motor to rotate when the nameplate AC brake voltage V_B is supplied to the brake rectifier terminals. There are certain cases where the brake rectifier can receive its voltage from the motor's terminal block, meaning that when power is applied to the motor it will simultaneously release the brake and start the motor. See page 3 for this description.

Brake Voltage Supplied from the Motor


There are specific instances when the brake voltage can be tapped from the motor's terminal block. The advantage of brake systems wired in this way is when power is applied to the motor, the brake releases, (requiring no additional brake supply power wiring). The brake can be wired to the motor terminal block under the following conditions: a single speed motor; the motor is started and run across the line (i.e., no inverter or electronic soft start). The connections shown on this page are for normal brake reaction time. For rapid brake reaction time, incorporate the contact as shown on the brake diagram located on the inside of the motor conduit box lid.

Brake Motor Connection


Single Speed Dual Voltage - Connection Diagram DT72

Example Motor Voltages:


230 /460 Volts - 60 Hz



Motor wired for low voltage.
Brake voltage matches low motor voltage.
Example: 230/460V Motor
Motor wired 230V
Brake voltage 230V



Motor wired for high voltage.
Brake voltage matches low motor voltage.
Example: 230/460V Motor
Motor wired 460V
Brake voltage 230V



Motor wired for high voltage.
Brake voltage matches high motor voltage.
Example: 230/460V Motor
Motor wired 460V
Brake voltage 460V


Brake Motor Connection

Single Speed Dual Voltage - YY/Y Connection Diagram DT79


Example Motor Voltages:

230YY/460Y Volts - 60 Hz


200YY/400Y Volts - 50 Hz



Motor wired for low voltage.
Brake voltage matches low motor voltage.
Example: 230/460V Motor
Motor wired 230V
Brake voltage 230V



Motor wired for high voltage.
Brake voltage matches low motor voltage.
Example: 230/460V Motor
Motor wired 460V
Brake voltage 230V



Motor wired for high voltage.
Brake voltage matches high motor voltage.
Example: 230/460V Motor
Motor wired 460V
Brake voltage 460V

Brake Motor Connection


Single Speed Dual Voltage - /Y Connection Diagram DT13

Examples Motor Voltages:


200 /346Y Volts - 60 Hz

330 /575Y Volts - 60 Hz


220 /380Y Volts - 50 Hz



Motor wired for low voltage.
Brake voltage matches low motor voltage.
Example: 200/346V Motor
Motor wired 200V
Brake voltage 200V



Motor wired for high voltage.
Brake voltage matches low motor voltage.
Example: 220/380V Motor
Motor wired 380V
Brake voltage 220V



Motor wired for high voltage.
Brake voltage matches high motor voltage.
Example: 220/380V Motor
Motor wired 380V
Brake voltage 380V

Re-adjusting the Brake Air Gap

A properly adjusted brake air gap is critical for correct operation. The following table indicates the required air gap measurement.

| Motor Size | Brake Size | Air Gap |
|---------------|--------------------------|-----------------------------|
| DT71 - DT100 | BM(G)05 - BM(G)4 | 0.010"-0.024" (0.25-0.6 mm) |
| DV112 - DV225 | BM(G)8 - BM31 | 0.012"-0.047" (0.3-1.2 mm) |
| DV180-DV225 | BM32-BM62 Double Disc | 0.016"-0.047" (0.4-1.2 mm) |

Prolonged use of the brake will wear the brake disc lining. This wear increases the air gap. When the air gap approaches its maximum value, the brake must be re-adjusted. To re-adjust the brake, follow the procedure below.

1. Remove the fan cover (14), fan snapping, fan (17), rubber seal (2), and any accessories at the fan end.
2. Insert a feeler gauge between the brake coil body (21) and the stationary disc (22), tighten the adjusting nuts (19) until the minimum value for the air gap is reached equally around the brake. With motor size 160L and up (brakes BM30 to BM62) first screw the threaded bushings (24) into the endshield. After setting the air gap, lock the bushings (24) against the coil body.
3. Ensure a play of 0.06" to 0.08" (1.5 to 2 mm) in the releasing arm. See "THE HAND RELEASE MECHANISM."

Replacement of the Brake Disc (26)

Extended operation of the brake may wear the brake disc (26) beyond acceptable limits. The thickness of the brake disc can be measured to determine if this has occurred.

| Motor Size | Brake Size | Min. Disc (26) Thickness |
|---------------|------------|--------------------------|
| DT71 - DT100 | BM05 - BM4 | 0.354" (9mm) |
| DV112 - DV225 | BM8 - BM62 | 0.394" (10mm) |

If the brake disc (26) is worn below the measurement given, it must be replaced. If the thickness is greater than the specification above, the brake disc is still usable and the brake can be re-adjusted.

The Hand Release Mechanism

Most of our brakes are supplied with a hand-operated release lever. This allows opening of the brake without applying power, allowing for adjustments on the driven machinery.

There are two brake release mechanisms available:

The "BMHR" (4) type requires a lever to be inserted into the release arm. To open the brake, pull the lever away from the motor. It will re-engage automatically, once the lever is released. The lever, when not used, is attached to the motor's cooling fins with clamps.

The screw-type "BMHF" (5) arrangement requires a hexagon key which, when turned clockwise, opens the brake.

Since the stationary disc (22) will move away from the coil body during the brake's operation, it is vital that there is free play (floating clearance) on the release arm of 0.060"-0.080" (1.5-2.0 mm). The springs (11) should be placed between the arm (7) and the nuts (12) to eliminate noise.

The brake release mechanism is not used to change the brake's torque setting. There must always be clearance on the lever.

Troubleshooting

Fault: Motor does not run

1. Check the motor and brake wiring for damage and proper connection.

2. At the motor, measure the line voltage, line current and motor resistance of all three phases.
3. If all three phases read a similar current value the following conditions may exist:

- The motor may be blocked by either an excessive external load, or problems in the reducer or the brake. In both cases, the motor should draw locked rotor (in-rush) current. Consult SEW-Eurodrive catalogs for these values. Release the brake mechanically, reset the air gap if needed, or disconnect the load from the output shaft.

- If the brake is at fault electrically see #4 below.

- If the current differs significantly from the rated locked rotor current, the motor is either an incorrect voltage, or it is jumpered for the wrong voltage.

4. If the brake can be released mechanically, but does not respond to voltage, check the brake for electrical problems.

- Make sure the wiring is according to the instructions. Pay special attention to the brake voltage.

- Energize the brake circuit and measure the AC voltage on the rectifier terminals 2 and 3 (BG/BGE rectifiers). The measured voltage should correspond to the nameplate inscription: "Brake V."

- Measure the DC voltage across terminals 3 and 5 of the brake rectifier which should be about 35% to 45% of the previously measured AC voltage.

- If there is no fault found to this point, measure the resistance of the brake coils. Disconnect the coil from the rectifier for this measurement. See the table on Page 2 for the brake coil resistance values.

- Measure the resistance of each brake coil lead to the brake coil body. This test should show an open circuit. If a short is found, the brake coil is damaged.

If the results of all these checks (electrical connection, mechanical checks and adjustments, and electrical tests) indicate that the brake should work, then the most likely cause of the brake's failure to release is a damaged brake rectifier.

Fault: Brake stopping time is too slow

If the brake has been operating well for some time and a gradual increase in stopping time has occurred, the release arm may have come in contact with the coil body. Verify that the brake release arm end play is correct, and check for excessive brake disc wear, (see previous instructions).


If the brake has been in operation for some time, and the stopping has become erratic, dust accumulation around the stationary disc guides may be the cause. Remove the brake's rubber sealing collar and clean with an air hose.

If the application is new, check the brake's wiring and air gap. If the brake is not wired for fast response, then changing the brake wiring to fast response will decrease the stopping time. Vertical motion and indexing applications may also require the fast response connection. Increasing the brake's torque may remedy the situation, but will also increase stress on the transmission.


On applications requiring excessive brake work, the lining's surface may become glazed due to extreme heat. The application of a BGE rectifier will improve this situation dramatically. BGE rectifiers are standard equipment on motors size DV 112 - DV225, but optional on the smaller sizes DT71-DT100. Contact SEW-Eurodrive for more information.

BM(G) Brake Cross Section and Exploded Views

BM(G) 05 - BM 15




BM 30/31



BM 32/62


Hand lever for manually disengaging the brake. will re-engage itself when released

Manual brake release screw for fixing brake in the dis-engaged position




- (1) Brake end shield
- (2) Rubber sealing collar
- (3) Braking springs
- (4) Hand release lever
- (5) Releasing screw
- (6) Closing plate
- (7) Release arm
- (9) Sealing ring
- (10) V-ring
- (11) Conical spring
- (12) Release
- (13) Stud
- (14) Fanguard
- (15) Grommet


- (16) Dowel pin
- (17) Fan
- (18) N/A
- (19) Brake adjustment nut
- (20) Retaining stud
- (21) Brake coil body
- (22) Stationary disc
- (23) Pressure ring
- (24) Setting sleeve
- (25) Dual brake pad stationary disc
- (26) Brake disc complete
- (27) Carrier
- (29) Cup Spring



Exploded view of the BM and BMG single-disk brake (motor sizes 71-160M)



Exploded view of the BM single-disk and double-disk brake (motor sizes 160L-225)



Troubleshooting Chart

| PROBLEM | CAUSE | REMEDY |
|---|---|--|
| Motor Overheats (Check temperature with instrumentation) | Motor not connected for proper supply voltage | Check connection diagram on conduit box cover and correct the wiring. |
| | Supply voltage varies outside the allowable tolerance causing an undervoltage or overvoltage condition. | Assure correct supply voltage. |
| | Insufficient cooling air volume due to: a. Low frequency operation on variable frequency drive. b. Obstructed air flow. | Increase air flow: a. Continuous running auxiliary fan. b. Ensure unobstructed air flow. |
| | Ambient temperature is too high. | Ensure cool air gets to the motor. Ducting may be required. |
| | Overload at rated voltage. Unit will draw current in excess of nameplate rating and run below rated speed. | Select a larger unit. |
| | Motor's allowable duty cycle is exceeded (too many starts per hour required). | The problem may or may not be solved with a larger motor. Contact SEW-Eurodrive. |
| | Single phasing due to break or loose connection in supply line or blown fuse. | Repair supply lines. Replace fuses. |
| Motor does not run. | Blown fuse. | Determine and correct cause of failure and replace fuse. |
| | Motor protection device activated. | Reset protective device. Identify and correct cause for device activation. |
| | Motor protection device faulty or will not reset. | Check protection device for faults. |
| Motor will not start or starts sluggishly. | Motor not connected for proper voltage. | Check connection diagram in conduit box cover and correct the wiring. |
| | Large voltage and/or frequency fluctuation at starting. | Ensure stable power supply. |
| For reduced voltage starting, motor will not start in Star Connection but will start in Delta connection. | Insufficient torque in Star Connection. | Start motor directly in Delta Connection if possible. Otherwise use a larger motor. |
| | Faulty contact in Star/Delta starter. | Correct fault condition. |
| Motor hums and draws high current. | Faulty or defective winding. | Have motor repaired by qualified service shop. |
| | Rotor dragging. | |
| Fuses blow or motor overcurrent protection trips immediately. | Short circuit in power supply conductors or in the motor. | Correct the fault condition. |
| | Motor has ground fault or winding to winding short circuit. | Have motor repaired by qualified service shop. |
| | Motor improperly connected. | Check connection diagram in conduit box cover and correct the wiring. |
| Motor runs in wrong direction. | Motor supply leads misconnected. | Switch two supply leads. |

Note: If, after proceeding through the Troubleshooting Chart, the motor is found to be defective, contact your nearest SEW-Eurodrive Assembly Center for warranty assistance or replacement parts.

Gearmotors and Gear Reducers

GENERAL


These operating instructions are intended to help you install and operate the drive. For trouble free service, proper installation and operation are essential. Additionally, these instructions contain important recommendations on maintenance.

Before shipment, every SEW-Eurodrive gear unit is tested, checked and properly packed. However, please inspect the drive immediately upon arrival for shortage or transit damage. Note the damage or shortage on the freight bill of lading and file a claim with the carrier. Also, notify SEW-Eurodrive of the shortage or damage.

LUBRICANTS


All gearmotors and gear reducers are supplied with the correct grade and quantity of lubricating oil for the specified mounting position. Exceptions include reducers shipped without input assemblies. The recommended lubricants are found on page 2.

LONG TERM STORAGE

If the drive is not installed immediately, it should be stored in a dry, protected area. If the drive is to be stored for an extended period of time and was not ordered from SEW for long term storage, contact your nearest SEW assembly plant for information on Long Term Storage or request  **Document #2115**.

Drives which are used for standby service should be stored as a sealed gearcase.

INSTALLATION OF COMPONENTS ON DRIVE SHAFTS

Do not hammer on the shafts. Hammering can cause brinelling of the reducer's bearings shortening the bearing life. We recommend heating the components to approximately 175°F (when possible) and sliding them on the shaft. This will reduce possible damage to the reducer's bearings.  **Document #2116**.

For both standard and metric SEW shaft tolerances, refer to the SEW Catalog or request  **Document #2154**.


Shaft couplings should be properly aligned to prevent vibration, coupling wear, and premature failure of the shaft bearings.

To prevent the output shaft and bearings from being subjected to excessive loads, the maximum overhung load, as shown in SEW-Eurodrive catalogs, should not be exceeded. Please consult our engineering department if the load may exceed the recommended figure given or where there are combined radial and axial loads. In such cases, the exact operating conditions must be stated including speed, direction of rotation, position, magnitude and direction of the external radial and axial loads being applied.

SHAFT MOUNTED REDUCERS

SEW-Eurodrive supplies the recommended hollowshaft mounting paste with every hollowshaft reducer. The mounting paste is to be applied on the keyed output shaft. The mounting paste is to aid in the prevention of rusting and fretting corrosion between the reducer hollowshaft and the shaft of the driven machine. The mounting paste will aid in shaft removal when necessary.

Warning! Always ensure exposed, rotating parts are properly covered to ensure safety.

For additional information on shaft mounted reducers, drive shaft configuration and tolerances, refer to the SEW-Eurodrive Catalog or request  **Documents #2201 and #2202**.

INSTALLATION AND OPERATION

The drive installation site should be selected to ensure:


- Ambient temperatures below 40°C (104°F).
- Unimpeded flow of air to the motor and variable speed units.
- Accessibility to the drain, level and breather plugs.
- Adequate space for the removal of brakemotor fanguard for brake adjustment and maintenance.

The drive unit should be mounted on a flat, vibration damping, and torsionally rigid structure. Careful alignment is critical. Mounting to an uneven surface will cause housing distortion. The flatness tolerance of the supporting surface should not exceed:


- For gear units size 80 and smaller — 0.004 inch.
- For gear units above size 80 — 0.008 inch.

For transportation, the units are supplied with the breather plug already mounted. After the unit is installed, the black rubber seal located on the breather MUST BE REMOVED (Fig. 1). In addition, the oil level should be checked. Remove the plated (non-painted) oil level plug. The oil level is correct when the surface of the oil is level with the lowest point of that tapped hole, the exception is S37. Units W20 and W30 are sealed in any position.

Fig. 1



After installation, the actual mounting position should be confirmed against the mounting position shown on the gear reducer nameplate. Adequate lubrication is only guaranteed if the unit is mounted in the specific nameplated mounting position.

Refer to the SEW Catalog or request  **Document #2111, #2112, #2113, or #2114 (R, F, K, or S, respectively)** if a specific mounting position diagram is needed.

MAINTENANCE

Warning! Always ensure equipment is secure and electrical power is off before removing or performing maintenance on the drive assembly. Oil levels and oil quality should be checked at regular intervals, determined by usage and the environment. Grease and oil should be changed per the recommendations on page 2. Check coupling alignment, chain or belt tension, and mounting bolt torque periodically. Keep the drive relatively free of dust and dirt.



For additional information, call the SEW FAXline, 1-800-601-6195, and request document number shown.

SEW EURODRIVE

**SOUTHEAST MANUFACTURING
& ASSEMBLY CENTER**
1295 Old Spartanburg Hwy, Lyman, SC 29365
(864) 439-7537 Fax: (864) 439-7830

SOUTHWEST ASSEMBLY CENTER
3950 Platinum Way, Dallas, TX 75237
(214) 330-4824 Fax: (214) 330-4724

MIDWEST ASSEMBLY CENTER
2001 West Main Street, Troy, OH 45373
(937) 335-0036 Fax: (937) 222-4104

EAST COAST ASSEMBLY CENTER
200 High Hill Road, Bridgeport, NJ 08014
(856) 467-2277 Fax: (856) 330-4724

WEST COAST ASSEMBLY CENTER
30599 San Antonio Road, Hayward, CA 94544
(510) 487-3560 Fax: (510) 487-6381



LUBRICANTS

| LUBRICATION SCHEDULE FOR SEW-EURODRIVE GEAR UNITS | | | | | | | | | |
|---|--|----------------------------------|---|---------------|--------------------------------------|-------------------------|----------------|----------------------|---------------------|
| Gear Reducer Type ¹⁾ | Lubrication Type | Ambient air temperature range °F | ISO Viscosity Grade | Mobil Oil Co. | CHEVRON Oil Co. | Shell Oil Co. | Texaco Oil Co. | BP Oil Co. | Kluber Oil Co. |
| R F K | Oil | +14 to +104 | VG220 | Mobilgear 630 | Chevron Non-Leaded Gear Compound 220 | Shell Omala Oil 220 | Meropa 220 | BP Energol GP-XP 220 | Kluberoil GEM 1-220 |
| | | -4 to +77 | VG150 VG100 | Mobilgear 629 | Chevron Non-Leaded Gear Compound 150 | Shell Omala Oil 100 | Meropa 150 | BP Energol GP-XP 100 | Kluberoil GEM 1-150 |
| S | Oil | +32 to +104 | VG680 | Mobilgear 636 | Chevron Non-Leaded Gear Compound 680 | Shell Omala Oil 680 | Meropa 680 | BP Energol GP-XP 680 | Kluberoil GEM 1-680 |
| | | +5 to +77 | VG220 | Mobilgear 630 | Chevron Non-Leaded Gear Compound 220 | Shell Omala Oil 220 | Meropa 220 | BP Energol GP-XP 220 | Kluberoil GEM 1-220 |
| General | Synth. Oil | +176 to -40 | Consult Factory For Use of Synthetic Oils | | | | | | |
| | Synth. Grease | +176 to -40 | Consult Factory For Use of Grease Filled Reducers | | | | | | |
| Ball & Roller Bearings | Grease Used for normal application Temp. Range: -22°F to 140°F | | | Mobilux EP2 | Chevron Dura-Lith EP2 | Shell Alvania Grease R3 | Multifak EP2 | BP Energrease LS3 | CENTOPLEX 2EP |

¹⁾ Applies to all reducers with or without motor and input shaft.

Oil levels and oil quality should be checked at frequent intervals, depending on usage. Oil changes are required at intervals of 10,000 operating hours or every two years, whichever comes first. If a synthetic oil lubricant is used, then this period can be extended to 20,000 operating hours or every four years, whichever comes first. In applications where hostile operating conditions exist, such as high humidity, corrosive environment, or large temperature changes, the lubricant should be changed at more frequent intervals.

The gear units W20 and W30 are supplied with a synthetic oil which is good for the life of the reducer, independent of the mounting position.

Grease packed bearings should be cleaned and regreased every 10,000 hours or 20,000 hours for synthetic grease. Input (high speed) bearings should not be overgreased. They should be filled with grease not to exceed 1/3 of the bearing's free volume. For output bearings and bearings with replaceable grease shields, fill to 2/3 of their free volume.

ATTENTION

When the recommended lubricant is not available, it is permissible to use a lubricant having equivalent characteristics but we do not recommend that lubricants of different brands be mixed. Under no circumstances should synthetic lubricants be mixed with one another or with one having a mineral base.

LUBRICANTS

The approximate lubricant in US gallons and liters per mounting position is as follows:

| Gear Unit | Mounting Position | | | | | | | | | | | |
|-----------|-------------------|---------------|------------------|--------------|------------------|--------|---------|--------|------------------|--------|------------------|--------|
| | M1 ¹⁾ | | M2 ¹⁾ | | M3 ²⁾ | | M4 | | M5 ²⁾ | | M6 ²⁾ | |
| | Gallons | Liters | Gallons | Liters | Gallons | Liters | Gallons | Liters | Gallons | Liters | Gallons | Liters |
| RX57 | 0.16 | 0.6 | 0.21 | 0.8 | 0.34 | 1.3 | 0.34 | 1.3 | 0.24 | 0.9 | 0.24 | 0.9 |
| RX67 | 0.21 | 0.8 | 0.21 | 0.8 | 0.45 | 1.7 | 0.50 | 1.9 | 0.29 | 1.1 | 0.29 | 1.1 |
| RX77 | 0.29 | 1.1 | 0.40 | 1.5 | 0.69 | 2.6 | 0.71 | 2.7 | 0.42 | 1.6 | 0.42 | 1.6 |
| RX87 | 0.45 | 1.7 | 0.66 | 2.5 | 1.27 | 4.8 | 1.27 | 4.8 | 0.77 | 2.9 | 0.77 | 2.9 |
| RX97 | 0.55 | 2.1 | 0.90 | 3.4 | 1.96 | 7.4 | 1.85 | 7 | 1.27 | 4.8 | 1.27 | 4.8 |
| RX107 | 1.03 | 3.9 | 1.48 | 5.6 | 3.06 | 11.6 | 3.14 | 11.9 | 2.03 | 7.7 | 2.03 | 7.7 |
| RXF57 | 0.13 | 0.5 | 0.21 | 0.8 | 0.29 | 1.1 | 0.29 | 1.1 | 0.18 | 0.7 | 0.18 | 0.7 |
| RXF67 | 0.18 | 0.7 | 0.21 | 0.8 | 0.40 | 1.5 | 0.45 | 1.7 | 0.26 | 1 | 0.26 | 1 |
| RXF77 | 0.24 | 0.9 | 0.40 | 1.5 | 0.63 | 2.4 | 0.66 | 2.5 | 0.42 | 1.6 | 0.42 | 1.6 |
| RXF87 | 0.42 | 1.6 | 0.66 | 2.5 | 1.29 | 4.9 | 1.24 | 4.7 | 0.77 | 2.9 | 0.77 | 2.9 |
| RXF97 | 0.55 | 2.1 | 0.95 | 3.6 | 1.88 | 7.1 | 1.85 | 7 | 1.27 | 4.8 | 1.27 | 4.8 |
| RXF107 | 0.82 | 3.1 | 1.56 | 5.9 | 2.96 | 11.2 | 2.77 | 10.5 | 1.90 | 7.2 | 1.90 | 7.2 |
| R17/R17F | 0.07 | 0.25 | 0.16 | 0.6 | 0.09 | 0.35 | 0.16 | 0.6 | 0.09 | 0.35 | 0.09 | 0.35 |
| R27/R27F | 0.07 (0.11) | 0.25 (0.4) | 0.18 | 0.7 | 0.11 | 0.4 | 0.18 | 0.7 | 0.11 | 0.4 | 0.11 | 0.4 |
| R37/R37F | 0.08 (0.26) | 0.3 (1) | 0.24 | 0.9 | 0.26 | 1 | 0.29 | 1.1 | 0.21 | 0.8 | 0.26 | 1 |
| R47/R47F | 0.18 (0.40) | 0.7 (1.5) | 0.42 | 1.6 | 0.40 | 1.5 | 0.45 | 1.7 | 0.40 | 1.5 | 0.40 | 1.5 |
| R57/R57F | 0.21 (0.45) | 0.8 (1.7) | 0.50 | 1.9 | 0.45 | 1.7 | 0.55 | 2.1 | 0.45 | 1.7 | 0.45 | 1.7 |
| R67/R67F | 0.29 (0.61) | 1.1 (2.3) | 0.69 (0.92) | 2.6 (3.5) | 0.74 | 2.8 | 0.85 | 3.2 | 0.48 | 1.8 | 0.53 | 2 |
| R77/R77F | 0.32 (0.79) | 1.2 (3) | 1.00 (1.14) | 3.8 (4.3) | 0.95 | 3.6 | 1.14 | 4.3 | 0.66 | 2.5 | 0.90 | 3.4 |
| R87/R87F | 0.61 (1.59) | 2.3 (6) | 1.77 (2.22) | 6.7 (8.4) | 1.90 | 7.2 | 2.03 | 7.7 | 1.66 | 6.3 | 1.72 | 6.5 |
| R97 | 1.22 (2.59) | 4.6 (9.8) | 3.09 (3.70) | 11.7 (14) | 3.09 | 11.7 | 3.54 | 13.4 | 2.99 | 11.3 | 3.09 | 11.7 |
| R107 | 1.59 (3.62) | 6 (13.7) | 4.31 | 16.3 | 4.46 | 16.9 | 5.07 | 19.2 | 3.49 | 13.2 | 4.20 | 15.9 |
| R137 | 2.64 (6.61) | 10 (25) | 7.40 | 28 | 7.79 | 29.5 | 8.32 | 31.5 | 6.61 | 25 | 6.61 | 25 |
| R147 | 4.07 (10.57) | 15.4 (40) | 12.29 | 46.5 | 12.68 | 48 | 13.74 | 52 | 10.44 | 39.5 | 10.83 | 41 |
| R167 | 7.13 (18.49) | 27 (70) | 21.66 | 82 | 20.61 | 78 | 23.25 | 88 | 17.44 | 66 | 18.23 | 69 |
| RF17 | 0.07 | 0.25 | 0.16 | 0.6 | 0.09 | 0.35 | 0.16 | 0.6 | 0.09 | 0.35 | 0.09 | 0.35 |
| RF27 | 0.07 (0.11) | 0.25 (0.4) | 0.18 | 0.7 | 0.11 | 0.4 | 0.18 | 0.7 | 0.11 | 0.4 | 0.11 | 0.4 |
| RF37 | 0.11 (0.26) | 0.4 (1) | 0.24 | 0.9 | 0.26 | 1 | 0.29 | 1.1 | 0.21 | 0.8 | 0.26 | 1 |
| RF47 | 0.18 (0.40) | 0.7 (1.5) | 0.42 | 1.6 | 0.40 | 1.5 | 0.45 | 1.7 | 0.40 | 1.5 | 0.40 | 1.5 |
| RF/RM57 | 0.21 (0.45) | 0.8 (1.7) | 0.48 | 1.8 | 0.45 | 1.7 | 0.53 | 2 | 0.45 | 1.7 | 0.45 | 1.7 |
| RF/RM67 | 0.32 (0.66) | 1.2 (2.5) | 0.71 (0.95) | 2.7 (3.6) | 0.71 | 2.7 | 0.82 | 3.1 | 0.50 | 1.9 | 0.55 | 2.1 |
| RF/RM77 | 0.32 (0.69) | 1.2 (2.6) | 1.00 (1.08) | 3.8 (4.1) | 0.87 | 3.3 | 1.08 | 4.1 | 0.63 | 2.4 | 0.79 | 3 |
| RF/RM87 | 0.63 (1.59) | 2.4 (6) | 1.8 (2.09) | 6.8 (7.9) | 1.88 | 7.1 | 2.03 | 7.7 | 1.66 | 6.3 | 1.69 | 6.4 |
| RF/RM97 | 1.35 (2.69) | 5.1 (10.2) | 3.14 (3.70) | 11.9 (14) | 2.96 | 11.2 | 3.70 | 14 | 2.96 | 11.2 | 3.12 | 11.8 |
| RF/RM107 | 1.66 (3.94) | 6.3 (14.9) | 4.20 | 15.9 | 4.49 | 17 | 5.07 | 19.2 | 3.46 | 13.1 | 4.20 | 15.9 |
| RF/RM137 | 2.51 (6.61) | 9.5 (25) | 7.13 | 27 | 7.66 | 29 | 8.59 | 32.5 | 6.61 | 25 | 6.61 | 25 |
| RF/RM147 | 4.33 (11.10) | 16.4 (42) | 12.42 | 47 | 12.68 | 48 | 13.74 | 52 | 11.10 | 42 | 11.10 | 42 |
| RF/RM167 | 6.87 (18.49) | 26 (70) | 21.66 | 82 | 20.61 | 78 | 23.25 | 88 | 17.17 | 65 | 18.76 | 71 |

¹⁾ On compound gear units the primary (larger) gear unit is provided with the oil quantity in parenthesis.

²⁾ On compound gear units having mounting positions M3, M5, or M6 the secondary (smaller) gear unit is provided with the oil filling of the M1 flanged mounting position.



For additional information on R-Series mounting positions, refer to the SEW Catalog or call the SEW FAXline, 1-800-601-6195, and request Document #2111.

LUBRICANTS

The approximate lubricant in US gallons and liters per mounting position is as follows:

| Gear Unit | Mounting Position | | | | | | | | | | | |
|---|-------------------|--------|---------|--------|---------|--------|---------|--------|---------|--------|---------|--------|
| | M1 | | M2 | | M3 | | M4 | | M5 | | M6 | |
| | Gallons | Liters | Gallons | Liters | Gallons | Liters | Gallons | Liters | Gallons | Liters | Gallons | Liters |
| F27 | 0.16 | 0.6 | 0.21 | 0.8 | 0.18 | 0.7 | 0.18 | 0.7 | 0.16 | 0.6 | 0.16 | 0.6 |
| F37 | 0.26 | 1 | 0.32 | 1.2 | 0.18 | 0.7 | 0.32 | 1.2 | 0.26 | 1 | 0.29 | 1.1 |
| F47 | 0.40 | 1.5 | 0.48 | 1.8 | 0.29 | 1.1 | 0.50 | 1.9 | 0.40 | 1.5 | 0.45 | 1.7 |
| F57 | 0.69 | 2.6 | 0.98 | 3.7 | 0.55 | 2.1 | 0.92 | 3.5 | 0.74 | 2.8 | 0.77 | 2.9 |
| F67 | 0.71 | 2.7 | 1.00 | 3.8 | 0.50 | 1.9 | 1.00 | 3.8 | 0.77 | 2.9 | 0.85 | 3.2 |
| F77 | 1.32 | 5 | 1.93 | 7.3 | 1.14 | 4.3 | 2.11 | 8 | 1.59 | 6 | 1.66 | 6.3 |
| F87 | 2.64 | 10 | 3.43 | 13 | 2.03 | 7.7 | 3.65 | 13.8 | 2.85 | 10.8 | 2.91 | 11 |
| F97 | 4.89 | 18.5 | 5.94 | 22.5 | 3.33 | 12.6 | 6.66 | 25.2 | 4.89 | 18.5 | 5.28 | 20 |
| F107 | 6.47 | 24.5 | 8.45 | 32 | 5.15 | 19.5 | 9.91 | 37.5 | 7.13 | 27 | 7.13 | 27 |
| F127 | 10.70 | 40.5 | 14.53 | 55 | 8.98 | 34 | 16.12 | 61 | 12.29 | 46.5 | 12.42 | 47 |
| F157 | 18.23 | 69 | 27.48 | 104 | 16.64 | 63 | 27.74 | 105 | 22.72 | 86 | 20.61 | 78 |
| FF27 | 0.16 | 0.6 | 0.21 | 0.8 | 0.18 | 0.7 | 0.18 | 0.7 | 0.16 | 0.6 | 0.16 | 0.6 |
| FF37 | 0.26 | 1 | 0.32 | 1.2 | 0.18 | 0.7 | 0.34 | 1.3 | 0.26 | 1 | 0.29 | 1.1 |
| FF47 | 0.42 | 1.6 | 0.50 | 1.9 | 0.29 | 1.1 | 0.50 | 1.9 | 0.40 | 1.5 | 0.45 | 1.7 |
| FF57 | 0.74 | 2.8 | 1.00 | 3.8 | 0.55 | 2.1 | 0.98 | 3.7 | 0.77 | 2.9 | 0.79 | 3 |
| FF67 | 0.71 | 2.7 | 1.00 | 3.8 | 0.50 | 1.9 | 1.00 | 3.8 | 0.77 | 2.9 | 0.85 | 3.2 |
| FF77 | 1.35 | 5.1 | 1.93 | 7.3 | 1.14 | 4.3 | 2.14 | 8.1 | 1.59 | 6 | 1.66 | 6.3 |
| FF87 | 2.72 | 10.3 | 3.49 | 13.2 | 2.06 | 7.8 | 3.73 | 14.1 | 2.91 | 11 | 2.96 | 11.2 |
| FF97 | 5.02 | 19 | 5.94 | 22.5 | 3.33 | 12.6 | 6.74 | 25.5 | 4.99 | 18.9 | 5.42 | 20.5 |
| FF107 | 6.74 | 25.5 | 8.45 | 32 | 5.15 | 19.5 | 10.17 | 38.5 | 7.27 | 27.5 | 7.40 | 28 |
| FF127 | 10.96 | 41.5 | 14.80 | 56 | 8.98 | 34 | 16.64 | 63 | 12.29 | 46.5 | 12.95 | 49 |
| FF157 | 19.02 | 72 | 27.74 | 105 | 16.91 | 64 | 28.01 | 106 | 22.99 | 87 | 20.87 | 79 |
| FA/FH/FV27 FAF/FHF/FVF27 FAZ/FHZ/FVZ27 | 0.16 | 0.6 | 0.21 | 0.8 | 0.18 | 0.7 | 0.18 | 0.7 | 0.16 | 0.6 | 0.16 | 0.6 |
| FA/FH/FV37 FAF/FHF/FVF37 FAZ/FHZ/FVZ37 | 0.26 | 1 | 0.32 | 1.2 | 0.18 | 0.7 | 0.32 | 1.2 | 0.26 | 1 | 0.29 | 1.1 |
| FA/FH/FV47 FAF/FHF/FVF47 FAZ/FHZ/FVZ47 | 0.40 | 1.5 | 0.48 | 1.8 | 0.29 | 1.1 | 0.50 | 1.9 | 0.40 | 1.5 | 0.45 | 1.7 |
| FA/FH/FV57 FAF/FHF/FVF57 FAZ/FHZ/FVZ57 | 0.71 | 2.7 | 1.00 | 3.8 | 0.55 | 2.1 | 0.95 | 3.6 | 0.77 | 2.9 | 0.79 | 3 |
| FA/FH/FV67 FAF/FHF/FVF67 FAZ/FHZ/FVZ67 | 0.71 | 2.7 | 1.00 | 3.8 | 0.50 | 1.9 | 1.00 | 3.8 | 0.77 | 2.9 | 0.85 | 3.2 |
| FA/FH/FV77 FAF/FHF/FVF77 FAZ/FHZ/FVZ77 | 1.32 | 5 | 1.93 | 7.3 | 1.14 | 4.3 | 2.11 | 8 | 1.59 | 6 | 1.66 | 6.3 |
| FA/FH/FV87 FAF/FHF/FVF87 FAZ/FHZ/FVZ87 | 2.64 | 10 | 3.43 | 13 | 2.03 | 7.7 | 3.65 | 13.8 | 2.85 | 10.8 | 2.91 | 11 |
| FA/FH/FV97 FAF/FHF/FVF97 FAZ/FHZ/FVZ97 | 4.89 | 18.5 | 5.94 | 22.5 | 3.33 | 12.6 | 6.61 | 25 | 4.89 | 18.5 | 5.28 | 20 |
| FA/FH/FV107 FAF/FHF/FVF107 FAZ/FHZ/FVZ107 | 6.47 | 24.5 | 8.45 | 32 | 5.15 | 19.5 | 9.91 | 37.5 | 7.13 | 27 | 7.13 | 27 |
| FA/FH/FV127 FAF/FHF/FVF127 FAZ/FHZ/FVZ127 | 10.30 | 39 | 14.53 | 55 | 8.98 | 34 | 16.12 | 61 | 11.89 | 45 | 12.29 | 46.5 |
| FA/FH/FV157 FAF/FHF/FVF157 FAZ/FHZ/FVZ157 | 17.97 | 68 | 27.21 | 103 | 16.38 | 62 | 27.48 | 104 | 22.46 | 85 | 20.34 | 77 |



For additional information on F-Series mounting positions, refer to the SEW Catalog or call the SEW FAXline, 1-800-601-6195, and request Document #2112.

LUBRICANTS

The approximate lubricant in US gallons and liters per mounting position is as follows:

| Gear Unit | Mounting Position | | | | | | | | | | | |
|---|-------------------|--------|---------|--------|---------|--------|---------|--------|---------|--------|---------|--------|
| | M1 | | M2 | | M3 | | M4 | | M5 | | M6 | |
| | Gallons | Liters | Gallons | Liters | Gallons | Liters | Gallons | Liters | Gallons | Liters | Gallons | Liters |
| K37 | 0.13 | 0.5 | 0.26 | 1 | 0.26 | 1 | 0.34 | 1.3 | 0.26 | 1 | 0.26 | 1 |
| K47 | 0.21 | 0.8 | 0.34 | 1.3 | 0.40 | 1.5 | 0.53 | 2 | 0.42 | 1.6 | 0.42 | 1.6 |
| K57 | 0.32 | 1.2 | 0.61 | 2.3 | 0.66 | 2.5 | 0.79 | 3 | 0.69 | 2.6 | 0.63 | 2.4 |
| K67 | 0.29 | 1.1 | 0.63 | 2.4 | 0.69 | 2.6 | 0.90 | 3.4 | 0.69 | 2.6 | 0.69 | 2.6 |
| K77 | 0.58 | 2.2 | 1.08 | 4.1 | 1.16 | 4.4 | 1.56 | 5.9 | 1.11 | 4.2 | 1.16 | 4.4 |
| K87 | 0.98 | 3.7 | 2.11 | 8 | 2.30 | 8.7 | 2.88 | 10.9 | 2.06 | 7.8 | 2.11 | 8 |
| K97 | 1.85 | 7 | 3.70 | 14 | 4.15 | 15.7 | 5.28 | 20 | 4.15 | 15.7 | 4.10 | 15.5 |
| K107 | 2.64 | 10 | 5.55 | 21 | 6.74 | 25.5 | 8.85 | 33.5 | 6.34 | 24 | 6.34 | 24 |
| K127 | 5.55 | 21 | 10.96 | 41.5 | 11.62 | 44 | 14.27 | 54 | 10.57 | 40 | 10.83 | 41 |
| K157 | 8.19 | 31 | 16.38 | 62 | 17.17 | 65 | 23.78 | 90 | 15.32 | 58 | 16.38 | 62 |
| K/KH167 | 9.25 | 35 | 26.42 | 100 | 26.42 | 100 | 33.03 | 125 | 22.46 | 85 | 22.46 | 85 |
| K/KH187 | 15.85 | 60 | 44.91 | 170 | 44.91 | 170 | 54.16 | 205 | 34.35 | 130 | 34.35 | 130 |
| KF37 | 0.13 | 0.5 | 0.29 | 1.1 | 0.29 | 1.1 | 0.40 | 1.5 | 0.26 | 1 | 0.26 | 1 |
| KF47 | 0.21 | 0.8 | 0.34 | 1.3 | 0.45 | 1.7 | 0.58 | 2.2 | 0.42 | 1.6 | 0.42 | 1.6 |
| KF57 | 0.34 | 1.3 | 0.61 | 2.3 | 0.71 | 2.7 | 0.79 | 3 | 0.77 | 2.9 | 0.71 | 2.7 |
| KF67 | 0.29 | 1.1 | 0.63 | 2.4 | 0.74 | 2.8 | 0.95 | 3.6 | 0.71 | 2.7 | 0.71 | 2.7 |
| KF77 | 0.55 | 2.1 | 1.08 | 4.1 | 1.16 | 4.4 | 1.59 | 6 | 1.19 | 4.5 | 1.19 | 4.5 |
| KF87 | 0.98 | 3.7 | 2.17 | 8.2 | 2.38 | 9 | 3.14 | 11.9 | 2.22 | 8.4 | 2.22 | 8.4 |
| KF97 | 1.85 | 7 | 3.88 | 14.7 | 4.57 | 17.3 | 5.68 | 21.5 | 4.15 | 15.7 | 4.36 | 16.5 |
| KF107 | 2.64 | 10 | 5.81 | 22 | 6.87 | 26 | 9.25 | 35 | 6.61 | 25 | 6.61 | 25 |
| KF127 | 5.55 | 21 | 10.96 | 41.5 | 12.15 | 46 | 14.53 | 55 | 10.83 | 41 | 10.83 | 41 |
| KF157 | 8.19 | 31 | 17.44 | 66 | 18.23 | 69 | 24.31 | 92 | 16.38 | 62 | 16.38 | 62 |
| KA/KH/KV37 KAF/KHF/KVF37 KAZ/KHZ/KVZ37 | 0.13 | 0.5 | 0.26 | 1 | 0.26 | 1 | 0.37 | 1.4 | 0.26 | 1 | 0.26 | 1 |
| KA/KH/KV47 KAF/KHF/KVF47 KAZ/KHZ/KVZ47 | 0.21 | 0.8 | 0.34 | 1.3 | 0.42 | 1.6 | 0.55 | 2.1 | 0.42 | 1.6 | 0.42 | 1.6 |
| KA/KH/KV57 KAF/KHF/KVF57 KAZ/KHZ/KVZ57 | 0.34 | 1.3 | 0.61 | 2.3 | 0.71 | 2.7 | 0.79 | 3 | 0.77 | 2.9 | 0.71 | 2.7 |
| KA/KH/KV67 KAF/KHF/KVF67 KAZ/KHZ/KVZ67 | 0.29 | 1.1 | 0.63 | 2.4 | 0.71 | 2.7 | 0.95 | 3.6 | 0.69 | 2.6 | 0.69 | 2.6 |
| KA/KH/KV77 KAF/KHF/KVF77 KAZ/KHZ/KVZ77 | 0.55 | 2.1 | 1.08 | 4.1 | 1.22 | 4.6 | 1.59 | 6 | 1.16 | 4.4 | 1.16 | 4.4 |
| KA/KH/KV87 KAF/KHF/KVF87 KAZ/KHZ/KVZ87 | 0.98 | 3.7 | 2.17 | 8.2 | 2.32 | 8.8 | 2.93 | 11.1 | 2.11 | 8 | 2.11 | 8 |
| KA/KH/KV97 KAF/KHF/KVF97 KAZ/KHZ/KVZ97 | 1.85 | 7 | 3.88 | 14.7 | 4.15 | 15.7 | 5.28 | 20 | 4.15 | 15.7 | 4.15 | 15.7 |
| KA/KH/KV107 KAF/KHF/KVF107 KAZ/KHZ/KVZ107 | 2.64 | 10 | 5.42 | 20.5 | 6.34 | 24 | 8.45 | 32 | 6.34 | 24 | 6.34 | 24 |
| KA/KH/KV127 KAF/KHF/KVF127 KAZ/KHZ/KVZ127 | 5.55 | 21 | 10.96 | 41.5 | 11.36 | 43 | 13.74 | 52 | 10.57 | 40 | 10.57 | 40 |
| KA/KH/KV157 KAF/KHF/KVF157 KAZ/KHZ/KVZ157 | 8.19 | 31 | 17.44 | 66 | 17.70 | 67 | 22.99 | 87 | 16.38 | 62 | 16.38 | 62 |



For additional information on K-Series mounting positions, refer to the SEW Catalog or call the SEW FAXline, 1-800-601-6195, and request Document #2113.

LUBRICANTS

The approximate lubricant in US gallons and liters per mounting position is as follows:

| Gear Unit | Mounting Position | | | | | | | | | | | |
|-----------------------------------|-------------------|--------|---------|--------|------------------|----------------|--------------------|-------------------|---------|--------|---------|--------|
| | M1 | | M2 | | M3 ¹⁾ | | M4 | | M5 | | M6 | |
| | Gallons | Liters | Gallons | Liters | Gallons | Liters | Gallons | Liters | Gallons | Liters | Gallons | Liters |
| S37 | 0.07 | 0.25 | 0.11 | 0.4 | 0.13 | 0.5 | 0.16 | 0.6 | 0.11 | 0.4 | 0.11 | 0.4 |
| S47 | 0.09 | 0.35 | 0.21 | 0.8 | 0.18 (0.24) | 0.7 (0.9) | 0.29 | 1.1 | 0.21 | 0.8 | 0.21 | 0.8 |
| S57 | 0.13 | 0.5 | 0.32 | 1.2 | 0.26 (0.32) | 1 (1.2) | 0.40 | 1.5 | 0.34 | 1.3 | 0.34 | 1.3 |
| S67 | 0.26 | 1 | 0.53 | 2 | 0.58 (0.82) | 2.2 (3.1) | 0.85 | 3.2 | 0.69 | 2.6 | 0.69 | 2.6 |
| S77 | 0.50 | 1.9 | 1.11 | 4.2 | 0.98 (1.43) | 3.7 (5.4) | 1.59 | 6 | 1.16 | 4.4 | 1.16 | 4.4 |
| S87 | 0.87 | 3.3 | 2.14 | 8.1 | 1.82 (2.75) | 6.9 (10.4) | 3.17 | 12 | 2.22 | 8.4 | 2.22 | 8.4 |
| S97 | 1.80 | 6.8 | 3.96 | 15 | 3.54 (4.76) | 13.4 (18) | 5.94 | 22.5 | 4.49 | 17 | 4.49 | 17 |
| SF37 | 0.07 | 0.25 | 0.11 | 0.4 | 0.13 | 0.5 | 0.16 | 0.6 | 0.11 | 0.4 | 0.11 | 0.4 |
| SF47 | 0.11 | 0.4 | 0.24 | 0.9 | 0.24 (0.29) | 0.9 (1.1) | 0.32 | 1.2 | 0.26 | 1 | 0.26 | 1 |
| SF57 | 0.13 | 0.5 | 0.32 | 1.2 | 0.26 (0.40) | 1 (1.5) | 0.42 | 1.6 | 0.37 | 1.4 | 0.37 | 1.4 |
| SF67 | 0.26 | 1 | 0.58 | 2.2 | 0.61 (0.79) | 2.3 (3) | 0.85 | 3.2 | 0.71 | 2.7 | 0.71 | 2.7 |
| SF77 | 0.50 | 1.9 | 1.08 | 4.1 | 1.03 (1.53) | 3.9 (5.8) | 1.72 | 6.5 | 1.29 | 4.9 | 1.29 | 4.9 |
| SF87 | 1.00 | 3.8 | 2.11 | 8 | 1.88 (2.67) | 7.1 (10.1) | 3.17 | 12 | 2.40 | 9.1 | 2.40 | 9.1 |
| SF97 | 1.96 | 7.4 | 3.96 | 15 | 3.65 (4.97) | 13.8 (18.8) | 6.24 | 23.6 | 4.76 | 18 | 4.76 | 18 |
| SA/SH37 SAF/SHF37 SAZ/SHZ37 | 0.07 | 0.25 | 0.11 | 0.4 | 0.13 | 0.5 | 0.16 | 0.6 | 0.11 | 0.4 | 0.11 | 0.4 |
| SA/SH47 SAF/SHF47 SAZ/SHZ47 | 0.11 | 0.4 | 0.21 | 0.8 | 0.18 (0.24) | 0.7 (0.9) | 0.29 ²⁾ | 1.1 ²⁾ | 0.21 | 0.8 | 0.21 | 0.8 |
| SA/SH57 SAF/SHF57 SAZ/SHZ57 | 0.13 | 0.5 | 0.29 | 1.1 | 0.26 (0.40) | 1 (1.5) | 0.42 | 1.6 | 0.32 | 1.2 | 0.32 | 1.2 |
| SA/SH67 SAF/SHF67 SAZ/SHZ67 | 0.26 | 1 | 0.53 | 2 | 0.48 (0.69) | 1.8 (2.6) | 0.77 | 2.9 | 0.66 | 2.5 | 0.66 | 2.5 |
| SA/SH77 SAF/SHF77 SAZ/SHZ77 | 0.48 | 1.8 | 1.03 | 3.9 | 0.95 (1.32) | 3.6 (5) | 1.56 | 5.9 | 1.19 | 4.5 | 1.19 | 4.5 |
| SA/SH87 SAF/SHF87 SAZ/SHZ87 | 1.00 | 3.8 | 1.96 | 7.4 | 1.59 (2.30) | 6 (8.7) | 2.96 | 11.2 | 2.11 | 8 | 2.11 | 8 |
| SA/SH97 SAF/SHF97 SAZ/SHZ97 | 1.85 | 7 | 3.70 | 14 | 3.01 (4.23) | 11.4 (16) | 5.55 | 21 | 4.15 | 15.7 | 4.15 | 15.7 |

¹⁾ On compound gear units the primary (larger) gear unit is provided with the oil quantity in parenthesis.

²⁾ When combined with a 2-pole motor at M4 mounting position, the oil quantity must be reduced to 0.28 gallons (1.05 liters).



For additional information on S-Series mounting positions, refer to the SEW Catalog or call the SEW FAXline, 1-800-601-6195, and request Document #2114.

For compound drives the R reducer requires its own oil filling as shown in the chart:

| Gear Unit | Mounting Position | | | | | |
|-----------|-------------------|--------|---------|--------|---------|--------|
| | M1/M3/M5/M6 | | M2 | | M4 | |
| | Gallons | Liters | Gallons | Liters | Gallons | Liters |
| R17 | 0.07 | 0.25 | 0.16 | 0.6 | 0.16 | 0.6 |
| R37 | 0.11 | 0.4 | 0.24 | 0.9 | 0.29 | 1.1 |
| R57 | 0.21 | 0.8 | 0.48 | 1.8 | 0.53 | 2 |
| R77 | 0.32 | 1.2 | 1.00 | 3.8 | 1.08 | 4.1 |
| R87 | 0.63 | 2.4 | 1.8 | 6.8 | 2.03 | 7.7 |
| R97 | 1.35 | 5.1 | 3.14 | 11.9 | 3.70 | 14 |
| R107 | 1.66 | 6.3 | 4.20 | 15.9 | 5.07 | 19.2 |